

# LEYSPEC Residual Gas Analyzer (RGA)

Software Manual 300781175\_002\_C0

## Part Numbers

220010V01  
220011V01  
220012V01  
220013V01  
220020V01  
220021V01





# Contents

	<b>Page</b>
<b>0 Introduction</b>	<b>5</b>
<b>1 Installation</b>	<b>6</b>
1.1 Specification of the PC	6
1.2 Software installation parameters	6
1.3 LEYSPEC RGA software operation	6
1.4 About the operation manual	7
1.5 PC setup	8
<b>2 Operation</b>	<b>9</b>
2.1 Start up the LEYSPEC software	9
2.2 Connection with a sensor	10
2.3 Toolbar and display screen	11
2.4 Recipe selection	15
2.5 Lighting sensor filament on	15
2.6 Start measurement	16
2.7 Stop measurement	16
2.8 Exit from the LEYSPEC software	16
<b>3 LEYSPEC software functions</b>	<b>17</b>
3.1 Measurement motion mode	17
3.2 Measurement mode	19
3.3 Change the unit of pressure	20
3.4 Create, edit and send a recipe	20
3.5 Screen display	29
3.6 Displaying gas names of mass number	36
3.7 Baseline subtract	37
3.8 Mass number calibration by analog mode	38
3.9 Sensitivity calibration mode	40
3.10 FIL/SEM ON integrated time display	45
3.11 Local mode setting	46
3.12 SEM interlock function	48
3.13 Procedure for abnormal partial pressure and warning	49
3.14 Analyzer protecting function	50
3.15 Correcting an error	54
3.16 Communication error	57
3.17 Save data	58
3.18 Display and print saved data	60
3.19 Setting the T.P. coefficient	60
3.20 Alarm log	60
<b>4 Others</b>	<b>61</b>
4.1 Menu before connecting the sensor	61
4.2 Measuring with a Faraday cup (FC)	65
4.3 Uninstall the LEYSPEC software	65
4.4 Glossary of terms	65
4.5 Residual Gas Analyzer operation flow	66
<b>5 Analyzing a function after loading the data file</b>	<b>67</b>
5.1 Processing the background	67

# Contents

	<b>Page</b>
5.2 Integral processing	67
<b>6 Host communication functions</b>	<b>70</b>
6.1 Overview	70
6.2 Detailed specifications of messages	70
<b>7 Analog output function 1</b>	<b>76</b>
7.1 Analog output	76
7.2 Output state	77
7.3 Setting analog output conditions	77
<b>8 Analog output function 2</b>	<b>78</b>
8.1 Analog output	78
8.2 Digital input	79
8.3 Digital output	79
8.4 Output state	79
8.5 Setting analog output and digital input/output conditions	80
<b>9 PLC communication</b>	<b>81</b>
9.1 Overview	81
9.2 Set the communication	82
9.3 Save data	83
9.4 Setting partial pressure alarms	83
9.5 Auto degas	83
9.6 Auto sensitivity calibration	84
9.7 Connect to a sensor	84
<b>10 CCLink-IE</b>	<b>85</b>
10.1 Overview	85
10.2 Setting the communication	86
<b>11 CCLink-IE2</b>	<b>87</b>
11.1 Overview	87
11.2 Setting the communication	87
<b>12 Sensor unit maintenance</b>	<b>88</b>
12.1 Overview	88
12.2 Sensor unit maintenance screen	88
12.3 Adjust FC offset function	88
12.4 Adjust SEM offset function	90
12.5 Initialize table of Mass No. Calibration	91
12.6 Status Check	92
12.7 Command send	93
<b>13 Optional IP Address setting function</b>	<b>94</b>
13.1 Overview	94
13.2 Optional IP Address setting screen	94

# Introduction

## 0 Introduction

This gas analysis software is used for the Leybold Residual Gas Analyzer (LEYSPEC RGA)/process monitor (LEYSPEC view/LEYSPEC Ultra).

This software has the following features:

- It is compatible with Windows 7 and Windows 10.
- The user interface is designed to be familiar to Windows users and intuitive to use.
- It can be used with multiple Leybold LEYSPEC RGA types.
- It is possible to connect up to 16 RGAs to a computer via an Ethernet hub.
- A function for automatic measurement motion is available via the pressure value from an external vacuum gauge. (\*Automatic measurement mode is an optional function. It cannot be used by the standard function.)

AM	Automatic measurement mode
HO	Host communication function
AO	Analog output function
AO2	Analog output function 2
PL	PLC communication
IE	CCLink-IE communication

---

\* Optional features may not be used together.

## 1 Installation

When "LEYSPEC software for Gas Analysis" is installed and used for Windows 7 and Windows 10, refer to [Software installation parameters](#) on page 6 and [LEYSPEC RGA software operation](#) on page 6. When using this software, understand and observe the limitations.

The LEYSPEC RGA software can be run on every edition of Windows 7 and Windows 10.

### 1.1 Specification of the PC

The PC specifications must meet the following requirements:

OS: Win 7, Win 8, Win 8.1, and Win 10 (WinMe, WinNT4 and later is recommended).

PC: The HDD has 2 MB of empty capacity (not including measurement data).

More than 128 MB RAM is available. (When the data is obtained continuously and kept long term, installing as much memory as possible is recommended.)

The CPU is Core i5 and more. (When measuring more than 8 sensors, CPU Core i7 or higher is recommended.)

The screen display area is 1024 x 768 and more.

A CD drive and Ethernet port is available.

A COM port (RS232C) is available. If a host communication function (optional) is used, more than one COM port is required. When using the analog output function (optional), it is necessary to add a DA Card manufactured by CONTEC CO., LTD. (Type: DA12-4 (PCI)).

### 1.2 Software installation parameters

- For Windows 7, Windows 8, Windows 8.1 or Windows 10, you must log on as the computer Administrator to install and run this software. The Administrator log on is required to register the Icon and registry, uninstall this software and save files.
- Do not install this software under a "Program Files" folder when it is installed for Windows 7, Windows 8, Windows 8.1 or Windows 10. Normal operation cannot be guaranteed because data files and other files would be saved elsewhere.

### 1.3 LEYSPEC RGA software operation

- For Windows 7, Windows 8, Windows 8.1 or Windows 10, after logging on as the computer Administrator, run the LEYSPEC RGA software.
- Do not switch to another user as this may affect the measurement operation of the LEYSPEC RGA software.
- Close the LEYSPEC RGA software before you log off.
- Do not have any background programs running during operation of the software.

# Installation

## 1.4 About the operation manual

Functions and operating procedures of the LEYSPEC software for Gas Analysis (referred to as this software throughout this manual) are stored on the SETUP CD-ROM for this software and can be freely displayed and printed out for reference.

To access the software manual:

1. Insert the install disk into the CD drive of the PC.
2. Operations are different with Windows OS.

### 1.4.1 Windows 8 / Windows 8.1 / Windows 10

When the SETUP CD is inserted into the CD drive of the PC, the screen is displayed as shown in Initial screen on page 14. Select "Run AutoRun.exe". If the screen shown in Account control screen on page 15 appears, select "Yes".




Fig. 0.1 Initial screen




Fig. 0.2 Option screen




Fig. 0.3 Account control screen

## 1.4.2 Windows 7

When the SETUP CD is inserted into the CD drive of the PC, a pop up will display asking you either to run the program via Auto play or to run the program from an "unknown" source depending on your computer set up.

Please select "Run AutoRun.exe" or "Allow" as required.

## 1.5 PC setup

- Turn off the power saving settings which make the computer switch off during measurement mode during measurement.
- If the COM port required is being used by another program on your PC, refer to the method and the recommended setting value for your operating system. Refer to [Windows 8 / Windows 8.1 / Windows 10](#) on page 8 or [Windows 7](#) on page 8.
- The COM port cannot be used for this software if it is used for another device such as a modem already.
- The COM port (RS232C) is available and a host communication function (optional) is used.

### 1.5.1 Windows 8 / Windows 8.1 / Windows 10

"Control Panel" → "System and Security" → "Device Manager" → "Ports (COM&LPT)" → "Properties of Communications Port (COM1)" → "Port Settings"

### 1.5.2 Windows 7

- When the display on the Control Panel is "View by: Category"

"Start" → "Control Panel" → "System and Security" → "Device Manager" → "Ports(COM&LPT)" → "Properties of Communications Port(COM1)" → "Port Settings"

- When the display on the Control Panel is "View by: Large icons / Small icons"

"Start" → "Control Panel" → "Device Manager" → "Ports(COM&LPT)" → "Properties of Communications Port(COM1)" → "Port Settings"

# Operation

## 2 Operation

### 2.1 Start up the LEYSPEC software

Double-click the icon that is displayed on the desktop and then start the program.

Shortly after starting up, check the free space of the data destination disk in sensors 1 through 16.

#### NOTICE:



If the free space is less than 10% of total capacity, the warning dialog box in *Free Space* on page 9 appears. If this warning dialog box appears, it is necessary to make free space by implementing the measures given in the dialog box.

(There is no effect to other operations if this warning dialog box is displayed.)

[Example] The following warning dialog box appears in case of:

1. Data destination is Drive C in sensor 1.
2. Data destination is Drive A in sensor 2.
3. Data destination is Drive E in sensor 3.
4. No problem for free space in Drive C.
5. Free space in Drive A and Drive E is less than 10% of total capacity.




Fig. 2.1 Free Space

After starting up, check for free space and warning dialog boxes appearing hourly (if at less than 10% capacity).

## 2.2 Connection with a sensor

After verifying the connected sensor number, check the number and select the sensor type and then click the <OK> icon. (When only a single sensor is connected and used to measure, check Sensor 1 only.)

In "Operation at starting", select from "only connects", "filament on" and "start measurement".

When measurement motion is in automatic measurement mode, "filament on" and "start measurement" are not selectable.

---

### NOTICE:

*Automatic measurement mode is an optional function.*



---

Please check "When starting, this dialog is displayed."

- only connects : Connect only to communicate with sensor. Operate with this condition for standard operation.
- filament on : After connecting sensor communication, turns filament on.
- Start measurement : After connecting sensor communication, turns filament on and start measurement.

Immediately after connecting the sensor by clicking the [OK] button, check if the model selected by [Sensor Setting] and the model of the actually connected sensor are the same. If not, the message shown in [Sensor type error](#) on page 10 will appear and the connection will be interrupted. In this case please change the sensor type in the drop down box.



Fig. 2.2 Sensor type error

# Operation

## 2.3 Toolbar and display screen

Screen just after starting up the software.





Fig. 2.3 Initial screen

- |  |                    |
|--|--------------------|
| 1. Mass No. (Scan/Analog), Time (Trend/He leak test) | 5. Toolbar group D |
| 2. Scroll back bar                                   | 6. Toolbar group C |
| 3. Ion current/Partial pressure/Concentration        | 7. Toolbar group B |
| 4. Display time                                      | 8. Toolbar group A |



(1) (2) (3) (4) (5) (6) (7) (8) (9) (10) (11) (12) (13) (14) (15) (16) (17) (18) (19) (20) (21)

Fig. 2.4 Toolbar group A: Displayed when the program is started

In "View" menu, "Main bar" is (1) to (5), "Sensor connection bar" is (6) to (21).

(1) Open and display saved data.

(2) Save the displayed data.

(3) Print out the displayed data (if a printer driver is installed.)

(4) Display a preview of the data print image (if a printer driver is installed.)

(5) Version information of this software [1], Version information of the connected LEYSPEC RGA power supply [3] and kind of optional function [2] are displayed.

(6) to (21) Connect the communication with sensor from 1 to 16. Please verify if each sensor is connected and power turns on. (An Ethernet hub is required when connecting two or more sensors.)

(The same operation can be done by clicking "Sensor" → "Sensor Setting" from the menu.)



Fig. 2.5 Toolbar group B: Set up the settings for each sensor

In "View" menu, "Sensor control bar" is (1) to (11) and "Recipe bar" is (12) to (19).

1. If in manual measurement mode, the filament and RF of the connected sensor are turned on.

To set the operation when turning on, follow "Operation setting of FIL button" in "Sensor" → "Control Panel" from the menu.

The above synchronises with the "MES" button controlling the SEM.

(Measurement = SEM ON / Measurement stop = SEM OFF)

(The same operation can also be done by clicking "sensor" → "filament ON/OFF" from the menu)

2. Turn light on at filament ON of the sensor.

3. Turn light on at SEM ON of the sensor.

4. Turn light on at RF ON of the sensor.

5. Reads the total pressure measurement value of the sensor, and lights up when total pressure interlock is on. During lighting, the filament does not turn light on and it could not measure. (Default setting is LEYSPEC view : 1e-2Pa, LEYSPEC ultra : 3e-3Pa (Setting value is determined by clicking "Sensor" → "T.P. interlock setting" of the menu. It works only when "active" is checked.)




Fig. 2.6 T. P. interlock setting Sensor 1 screen

6. Read set point output of external vacuum gauge and turn light on during filament interlock of sensor works. It is available only during reading set point of external vacuum gauge.

7. If in manual measurement mode, the measurement begins.

(The same operation can be done by clicking "Sensor" → "Mes. Start / Stop" from the menu.)

8. Turn light on after starting measurement.

9. Turn light on when the value is over the setting partial pressure value (Error setting) during trend / He leak test mode.

# Operation

10. Turn light on when the value is over the setting partial pressure value (Warning setting) during trend / He leak test mode.

11. Turn light on when total pressure setting value of sensor is read and the value is over total pressure set point value.

(Setting value is determined by clicking "Sensor" → "T.P. set point setting" of the menu. It works only when "Active" is checked.)




Fig. 2.7 T. P. setpoint setting Sensor 4 screen

12. Send the recipe of the Scan mode selected in previous measurement and switch measurement mode to Scan mode.

13. Send the recipe of the Trend mode selected in previous measurement and switch measurement mode to Trend mode.

14. Send the recipe of Analog mode selected in previous measurement and switch measurement mode to Analog mode. Also, switch to manual measurement mode automatically.

15. Send the recipe of the Sensitivity Calibration mode selected in previous measurement and switch measurement mode to the Sensitivity Calibration mode. Also, switch to manual measurement mode automatically.

16. Send the recipe of Degas mode selected in previous measurement and switch measurement mode to Degas mode. Also, switch to manual measurement mode automatically.

17. Send the recipe of the He leak test mode selected in previous measurement and switch measurement mode to He leak test mode.

18. Edit or send the recipe that is sent to the connected sensor. (The same operation can be done by clicking "Setting" → "Recipe" from the menu.)

19. Display the recipe that is selected currently.



(1) (2) (3) (4) (5) (6) (7) (8) (9) (10) (11) (12) (13) (14)

Fig. 2.8 Toolbar group C: Set displayed data. Click "View" → "Display bar" to display.

(1) Display data log of Y-axis.

(2) Display data linear of Y-axis.

(3) Set various display of data.

(The same operation can be done by clicking "setting" → "display" from the menu.)

(4) Display and non display the legend of data.

(5) Switches over the trend graph display ratio when simultaneously displaying the bar graph and trend graph of the scan mode data to "1/2", "1/3", "1/4", "1/5" and "No display" in that order. Switches over the bar graph display ratio when simultaneously displaying the trend graph and bar graph of the trend / He leak test mode data to "1/2", "1/3", "1/4", "1/5" and "No display" in that order.

(6) Edit the comment that is displayed in the data.


(The same operation can be done by clicking "Setting" → "Input a comment" from the menu.)

(7) to (10) Scroll displayed data to previous or next.

(11) to (12) The expansion and the reduction of the range of the display of a horizontal axis of data are done. A center position of the expansion and the reduction is the points to have clicked the mouse on data.

(13) Optimise the data display of horizontal axis range.

(14) Display the latest data.



(1) (2)

Fig. 2.9 Toolbar group D: Execute post-processing of data. Click "View" → "Toolbar" to display.

(1) Subtract the designated data from all data.

(The same operation can be done by clicking "Tools" → "Background" from the menu.)

(2) Conducts integral calculation of a designated range.

(The same operation can be done by clicking "Tools" → "Integrate" from the menu.)

Toolbar group E : Switch measurement motion mode. (Manual measurement/ Automatic measurement) Click "View" → "Measurement mode bar" to display.

---

## NOTICE:

*Automatic measurement mode is an optional function.*



(1) (2)

Fig. 2.10 Automatic measurement mode

(1) Switch measurement motion to manual measurement mode.

(2) Switch measurement motion to automatic measurement mode.

# Operation

(The same operation can be done by clicking "Setting" → "Measurement mode" from the menu.)




Fig. 2.11 Measurement mode screen

## 2.4 Recipe selection

When starting up just after the installation, the recipe of the Analog mode (the default recipe) is set.

The default recipe of the He leak test mode and the Trend mode is also registered and can be selected.

The recipe can be edited and be set with the icon of (18) and (19) in toolbar group B.



Fig. 2.12 Group B toolbar

Please refer to "4. Details (3) Create, edit and send recipe" for more information.

## 2.5 Lighting sensor filament on

If in manual measurement mode, click the (1) icon of toolbar group B, turn the lamps (2) and (4) on, which turns the sensor filament and RF on. If in automatic measurement mode, turn the lamps (2) and (4) on during measurement start delay time if applicable to the automatic measurement start function.



Fig. 2.13 Automatic measurement mode

It is available to set up if you turn both FIL and RF ON/OFF or one half of them synchronises with (1) icon motion. Set up at "Operation setting of FIL button" group after displayed "Control Panel" dialog by clicking "Sensor" → "Control Panel" from the menu. Turning SEM ON/OFF synchronises with the (7) icon of toolbar group B. (Measurement = SEM ON / Measurement stop = SEM OFF).

In the dialog of the "Control Panel", set the Ion Collector selection (FC or SEM.), the SEM voltage (-1kV ~ -3kV, selecting filaments (1 or 2) and setting emission current: 50 or 500 or 1000 uA).




Fig. 2.14 Control panel screen

- A. Control panel dialog (LEYSPEC view)
- B. Control panel dialog (LEYSPEC Ultra)

## 2.6 Start measurement

If in manual measurement mode, after clicking the (7) icon of toolbar group B, turn lamp (3) and (8) on and indicate to start measurement. If in automatic measurement mode, turn lamp (3) and (8) on during measurement start delay time if it is applicable to automatic measurement start function.



Fig. 2.15 Toolbar group B

## 2.7 Stop measurement

If measurement motion is in manual measurement mode, after clicking (7) icon of toolbar group B, turn lamp (3) and (8) off and stop measurement. If measurement motion is in automatic measurement mode, turn lamp (3) and (8) off. If it is applicable to automatic measurement, stop function.

Turn lamp (3) and (8) off and stop measurement if the total pressure measurement value is over SEM interlock setting value when measuring SEM interlock in effective state. Refer to "details (10) About SEM interlock function" for more information.

(If the type of data to save is set to "Confirmation" by recipe setting, the file saving dialog is displayed in stopping measurement.)

## 2.8 Exit from the LEYSPEC software

After stopping measurement, click the Exit Windows icon or click "File" → "Exit" from the menu to quit this software. All running measurements/units will be turned off at the same time as the program is ended.

# LEYSPEC software functions

## 3 LEYSPEC software functions

### 3.1 Measurement motion mode

The software has an automatic measurement function for starting measurement automatically by pressure value imported from an external vacuum gauge.

- |                            |   |   |
|----------------------------|---|---|
| Manual measurement mode    | : | Turn on FIL/RF/SEM and measurement start, and turn off SEM/FIL/RF and measurement stop performed manually from the menu and by clicking the button  |
| Automatic measurement mode | : | Automatic series operation to turn FIL/RF/SEM on and measurement start, or automatic series operation to turn SEM/FIL/RF off and measurement stop in conjunction with the pressure value imported from the external vacuum gauge. |

If all the conditions at the time of sensor connection are in agreement with (1-1), motion mode immediately after sensor connection (default) will turn into automatic measurement mode. If not, manual measurement mode will be used.

#### 3.1.1 Condition for selectable automatic measurement mode

Automatic measurement mode is selectable under the following conditions:

- Pres. is selected at "Analog ch1" group of "Analog input setting" dialog.
- Current recipe is in Scan mode, Trend mode or Helium leak test mode.

#### 3.1.2 Motion of manual measurement mode

- You cannot handle measurement motion and turn on/off FIL etc in automatic measurement mode.
- A confirmation message appears if switched to automatic mode during measurement in manual mode.




Fig. 3.1 Confirmation of measurement mode change screen

Measurement is stopped and switched to automatic measurement mode with FIL etc still ON (\*) by clicking [Yes] button. To continue measuring in manual mode, click the [No] button.

\* FIL etc turns OFF by obtaining an analog ch1 input value immediately after switching to automatic measurement mode and that pressure value is applicable to the measurement stop condition.

#### 3.1.3 Motion of automatic measurement mode

- In the state where it does not measure, importing (\*1) the pressure value of analog ch1 input and the confirmation (\*2) of whether applicable to automatic

# LEYSPEC software functions

measurement start conditions are constantly (about 1 second intervals) handled until measurement begins (\*3) automatically.

\* 1 - For a hot cathode vacuum gauge, commute pressure by substitute obtained analog ch1 inputting data to pressure commuting formula which is set up in "Analog input setting" dialog.

If the type of vacuum gauge is a pirani, adjust pressure using the appendix [hot cathode non-linear output data] (\*4).

For a pirani vacuum gauge, commute pressure by appendix [pirani log calculating formula] (\*4).

\* 2 - For automatic measurement start (hot cathode vacuum gauge):  
 $5E-8Pa < \text{pressure equivalent} \leq \text{automatic measurement start pressure value}$ .

For automatic measurement start (pirani vacuum gauge):  
 $\text{pressure equivalent} \leq \text{automatic measurement start pressure value}$ .

\* 3 - If the automatic measurement start condition is carried over from previous measurements, a delayed start will occur and it will turn on after a period of time. If an automatic measurement start condition is attempted during the start delay time, automatic measurement motion is stopped and the process of \*1 and \*2 will be kept until that condition is restored.

\* 4 - Refer to "5. Other (1-3) Analog input setting [pirani non-linear output data] or [pirani log calculating formula]".

Starting measurement will turn FIL, RF and SEM on automatically if the automatic measurement start condition was preselected in the measurement start delay time.

Confirm if (\*5) corresponds with the automatic measurement stop condition for each measurement using the analog ch1 input, even if it is still measuring.

\* 5 - For automatic measurement stop (hot cathode vacuum gauge):

$\text{automatic measurement stop pressure value} < \text{pressure equivalent}$  or  $\text{pressure equivalent} \leq 5E-8Pa$ .

For automatic measurement stop (pirani vacuum gauge):

$\text{automatic measurement stop pressure value} < \text{pressure equivalent}$ .

- If in automatic measurement stop condition, measurement will stop automatically and turn FIL, RF and SEM off.
- The process of \*1 and \*2 restarts after switching to automatic mode from manual mode, and after automatic mode stops.
- You cannot turn FIL etc ON/OFF during manual measurement motion. It can be turned off by switching to manual measurement mode whilst automatic measurement mode is running. A confirmation message appears if you switch to manual mode during automatic mode.

# LEYSPEC software functions

Measurement is stopped and switched to manual measurement mode with FIL etc still ON by clicking the [Yes] button. To continue measuring in automatic mode, click the [No] button.

- If you change the measurement recipe to analog mode, sensitivity calibration mode or degas mode whilst in automatic measurement mode, it will switch to manual mode automatically. You cannot switch to automatic measurement mode in these measurement recipe modes.
- The graph display and numerical number of analog ch1 is not available for a pirani vacuum gauge.

## 3.2 Measurement mode


In this software, there are six measurement modes.

Scan mode	:	Mode to scan a set range continuously and measure mass spectrum. The setting mass number depends on the specification of the connected sensor.
Trend mode	:	Mode to measure selected mass number and measure the change per time of each measurement mass number. You can select up to a maximum of 20 ch. The setting mass number depends on the specification of the connected sensor.
Helium leak test mode	:	Mode to measure the change per time of mass number 4 only. The measurement mass number is fixed at 4, but other conditions can be changed as required.
Analog mode	:	Mode to provide peak top setting value of the analog spectrum of sensor that is used on scan mode or trend mode. This is called mass number adjust. In this mode, the analog spectrum of the sensor is verified.
Sensitivity calibration mode	:	Mode to calibrate the sensitivity of the SEM of the sensor. The supplied voltage to the SEM is moved up or down to keep the setting of the ion current.
Degas mode	:	Mode to degas the ion source of the sensor.


# LEYSPEC software functions

## 3.3 Change the unit of pressure

1. Close the "Sensor Setting" screen which shows up after activating LEYSPEC RGA software by clicking [Cancel].



2. Click [Setting] and [Setting Pressure Unit].



3. Select the unit you require. The unit you select will become the default unit.



## 3.4 Create, edit and send a recipe

Recipes can control and manage various sensor setting items on analyzing gas. The user can setup and control 60 recipes.

# LEYSPEC software functions

(Recipe 0-59: These recipes are recipes which the user can edit. 60-99: These recipes are the default recipes which cannot be edited with this software.)

After clicking the (18) icon of toolbar group B, the Recipe sensor 1 select screen is displayed and it can setup, display and send a recipe.





Fig. 3.2 Recipe sensor 1 select screen

(After checking “Selectable recipes only”, only recipes that could be received by the connected sensor will be displayed.)



(1) (2) (3) (4) (5)

Fig. 3.3 Toolbar in recipe setting dialog

- (1) Create a new recipe.
- (2) Edit a recipe that is selected in the dialog box.
- (3) Copy a selected recipe.
- (4) Paste the recipe that was copied.
- (5) Delete a selected recipe.

### 3.4.1 Create a recipe

- After double-clicking a blank recipe or clicking the (1) icon of the toolbar of the recipe select dialog box, set a recipe on the new recipe screen.

# LEYSPEC software functions




Fig. 3.4 New recipe screen

- Recipe No. : Displays the number of the editing recipe.
- Sensor type : Select the type of connecting sensor.
- Recipe name : Input the name of the editing recipe. The input text is displayed on top of the measurement screen or the dialog of the selecting recipe.
- Mode : Select the scan mode for the editing recipe.
- Sweep speed : Select the speed of a measurement for each mass from 50, 100, 200, 500, 1000, and 2000 ms. Setting 200 ms or more is recommended because of data variances according to the measurement speed.
- Total pressures and analog inputs : Sets analog input, record data of total pressure of sensor.
- Partial pressure ratio : The measured value ratio between each measurement channel is calculated and recorded.  
The mass numbers of the numerators (left list) and denominators (right list) for use in ratio calculation are selected.  
Either Analog1 or Ratio1 can be selected (as well as Analog2 and Ratio2).
- Unit of Y-axis : Set the unit of data record. Select from ion current [A], partial pressure [Pa] (or [Torr] or [mbar]) and concentration [ppm]. Ion current [A] is fixed in the analog/sensitivity calibration/degas mode.

# LEYSPEC software functions

---

## NOTICE:



Partial pressure [Torr] or [mbar] is an optional function. It cannot be used by the standard function. The explanation of this manual is described by partial pressure [Pa]

---

When partial pressure [Pa] (or [Torr] or [mbar]) is selected, pressure is displayed based on the data that is set in following "Ref. to pressure display".

Selecting concentration [ppm] conducts calculation, where the maximum ion current value in a mass number under measurement is 100%, and displays it on a graph.

<Concentration calculating formula >  $C_n = (I_n / I_{max}) / 1E.6$

$C_n$  : Concentration of mass number n

$I_n$  : Ion current value of mass number n

$I_{max}$  : Maximum ion current value in mass number measurement

Reference to partial Pressure : Select the reference data when the unit of data record is selected partial pressure.

[Calibration value] : Display the partial pressure of all gas based on the correlation of the ion current and pressure that is set in sensitivity calibration mode.

[Total pressure] : The partial pressure of all gases is displayed according to the total pressure data.

[Analog ch1] : Display the partial pressure of all gas based on the pressure measurement value that is recorded in analog 1 input.

[Analog ch2] : Display the partial pressure of all gas based on the pressure measurement value that is recorded in analog 2 input.

Measurement end time : Sets the method of terminating measurement.

[Cont.] : Continues measurement unless measurement terminating processing is conducted by the user.

[Spec.] : Measurement ends automatically with the elapse of the set time.

[Repeat] : Data file is automatically updated with the elapse of the set time (when data is saved). After updating the data file, clear the data and continue measurement, where the next data is the first time of measurement. This action is repeated unless measurement terminating action is taken by the user.

[Cont.] will be selected forcibly when the ending time is 0 hour 0 minute even if [Spec.] or [Repeat] is selected.

If measurement mode is in automatic measurement mode, [Spec.] and [Repeat] can be controlled. However, set time is not accurate because measurement start/stop are affected by acquisition pressure value from the external vacuum gauge. We recommend setting [Cont.] in automatic measurement mode.

Sampling interval : When [Auto] is checked, measurement data is updated and is saved each time measurement is repeated by one scan (when saving data).

Removing the check mark from [Auto] and setting a time updates the measurement data at each set time and saves the data (when saving data).

# LEYSPEC software functions

Normally, [Auto] is set, but when saving data for a long time, set a suitable time.

The set value range when the check mark is removed from [Auto] is 0.5 sec (trend / He leak test) and 1 sec (scan) to 1000 sec, but the measurement data updating interval may be slightly longer depending on the number of sensors connected and the set conditions of the recipe. It also varies slightly depending on the condition of the PC or the application start condition.

- Data save : Set the method to save the data.
- [AutoSave] : The file name is generated from the clock of the PC automatically, and when the measurement stops, the measurement data is written in HDD when the measurement is completed.
- Example:  
Start sensor 1 measurement on 10:10 January 13, 2001 by scan mode, the file name would be S1\_010113\_101000.qss
- [Confirmation] : The data saving dialog appears when measurement is stopped. The default filename is assigned according to the same file naming rule as [Autosave].  
Save the data by clicking the [Save] button and close the dialog by clicking the [Cancel] button without saving the data.
- [at Sampling] : Save data at each measurement sampling. The filename is assigned according to the same file naming rule as [AutoSave].  
Unlike [AutoSave] or [Confirmation] which saves data in a batch when measurement has stopped, this mode saves data in real time during measurement. Even if PC stops working during measurement, data can be saved by selecting [at Sampling]. If data is always saved or continuous measurement is made for an extended time, we recommend you select [at Sampling].  
\* If the disk is at full capacity and data cannot be saved, measurement is crashed and an error message appears. It is necessary to make free space to avoid these crashes.
- [No Save] : The confirmation dialog appears when data is not saved but the connection window is closed. Clicking the [Yes] button saves data and clicking the [No] button shuts off the sensor without saving data. Clicking the [Cancel] button stops sensor shutoff processing.  
\* Data displayed on the screen can be saved by clicking [File]->[Save] in any setting of [AutoSave], [Confirmation] or [NoSave]. The default filename displayed at this time is assigned according to the same file naming rule as [AutoSave], but it is assigned at the current time of the PC rather than the measurement start time.
- Ranges of sweep mass number : In Scan/Analog mode, set the first and last mass number of measurement.  
In Trend mode, set a required mass number. Mass number can be set to any channel number regardless of its magnitude, but checked mass numbers are automatically arranged in order of increasing number by clicking the [Save] button.

# LEYSPEC software functions

<input checked="" type="checkbox"/> Ch 1	2	<input checked="" type="checkbox"/> Ch 6	44	<input type="checkbox"/> Ch11	200	<input type="checkbox"/> Ch16	200
<input checked="" type="checkbox"/> Ch 2	18	<input type="checkbox"/> Ch 7	200	<input type="checkbox"/> Ch12	200	<input type="checkbox"/> Ch17	200
<input checked="" type="checkbox"/> Ch 3	28	<input type="checkbox"/> Ch 8	200	<input type="checkbox"/> Ch13	200	<input type="checkbox"/> Ch18	200
<input checked="" type="checkbox"/> Ch 4	32	<input type="checkbox"/> Ch 9	200	<input type="checkbox"/> Ch14	200	<input type="checkbox"/> Ch19	200
<input checked="" type="checkbox"/> Ch 5	40	<input type="checkbox"/> Ch10	200	<input type="checkbox"/> Ch15	200	<input type="checkbox"/> Ch20	200

In the He leak test mode, Ch1 is fixed at mass number 4, and Ch2 - Ch20 are set to the measurement prohibition and cannot be changed.

<input checked="" type="checkbox"/> Ch 1	4	<input type="checkbox"/> Ch 6	200	<input type="checkbox"/> Ch11	200	<input type="checkbox"/> Ch16	200
<input type="checkbox"/> Ch 2	200	<input type="checkbox"/> Ch 7	200	<input type="checkbox"/> Ch12	200	<input type="checkbox"/> Ch17	200
<input type="checkbox"/> Ch 3	200	<input type="checkbox"/> Ch 8	200	<input type="checkbox"/> Ch13	200	<input type="checkbox"/> Ch18	200
<input type="checkbox"/> Ch 4	200	<input type="checkbox"/> Ch 9	200	<input type="checkbox"/> Ch14	200	<input type="checkbox"/> Ch19	200
<input type="checkbox"/> Ch 5	200	<input type="checkbox"/> Ch10	200	<input type="checkbox"/> Ch15	200	<input type="checkbox"/> Ch20	200

Pressure warning: : In setting the mass number to measure by Trend / He leak test mode, set the value of the error and warning output. After checking "Active" and clicking on "Setting", set each setting value by following the dialog.

In the trend mode, the error and alarm output values against the partial pressure ratio can also be set.

Fig. 3.5 Error and warning output setting screen

- The input value should be “Error(↓)”<“Warning(↓)”<“Warning(↑)”<“Error(↑)”
- Only the checked item is available for each setting value.

# LEYSPEC software functions

- When "Keep output" is checked, the error output is saved even though measuring data clears each setting value.
- An error is output when the value is over setting error or warning value and recognised continuously the setting number in "Judgment counts".




Fig. 3.6 calibration by reference gas

- Mass number : Set mass number of object to calibrate sensitivity.
- Calib. Pressure : Set pressure value to calculate partial pressure.
- Calib.current : Set target setting value for ion current.

# LEYSPEC software functions




Fig. 3.7 Calibration by SEM gain

Mass number : Set mass number of object to calibrate sensitivity.

Gain : Set target gain.(Gain = SEM ion current / FC ion current)




Fig. 3.8 Create a degas recipe

# LEYSPEC software functions

- Degas mode : Set arrival time until maximum degas output. Check "Slow" for standard operation.  
Set maximum degas output.
- Max power : Set the normal setting value according to the model as follows:  
LEYSPEC view : 100%  
LEYSPEC ultra : 100%
- Degas time : Set time to degas.  
Set the normal setting value according to the model as follows:  
LEYSPEC view : 2Hr  
LEYSPEC ultra : 2Hr

- Maximum output and time of the degas changes if the analyzer tube is contaminated.
- Degas with 1E-4Pa or less. The analyzer tube would be at a higher risk of contamination if degassing was done in a high pressure area.

When you are finished setting the recipe, click "Apply" or "Save". Click "Apply" to save when setting the recipe description and to send to the sensor. Click "Save" to save the setting recipe description, but it will not be sent to the sensor.



Fig. 3.9 Save the recipe

### 3.4.2 Send a recipe

After selecting sending recipe in the dialog on recipe selection, click the "Select" icon.

### 3.4.3 Verify a recipe

After clicking the (19) icon of toolbar group B, display dialog to set recipe (3-1), the description of the current setting recipe is displayed.

The description of the recipe can be changed in this dialog. After making the change and clicking "Apply", the setting description of the recipe will be amended, saved and sent to the sensor. You cannot change the setting description in the default recipe.

### 3.4.4 Setting a recipe

- In the multi sensor connection, the recipe cannot be changed when it is used in an active window sensor or another window.
- You cannot change the recipe during measurement.
- A recipe that is newly created starts with the default recipe settings default recipe.
- The items that can be set varies depending on the connected sensor type.

# LEYSPEC software functions

## 3.5 Screen display

### 3.5.1 Scan mode




Fig. 3.10 Scan mode screen 1

- |                           |                        |
|---------------------------|------------------------|
| 1. Y-axis min/max setting | 4. Recipe name comment |
| 2. Date and click point   | 5. File name status    |
| 3. Measurement time       | 6. Scroll back bar     |




Fig. 3.11 Scan mode screen 2

- |                                |                         |
|--------------------------------|-------------------------|
| 1. Legend of trend             | 3. Display - trend data |
| 2. Data in bar cursor position |                         |

File name, status : Displays the condition of the connecting sensor and display "data file name" when the obtained data is displayed in the window.

# LEYSPEC software functions

- The recipe name, comment : Displays the recipe of the displayed data and comment. The comment can be input by using the toolbar group C (6) icon.
- Display measurement time : Displays real time during measuring and display time when data is obtained in displaying obtained data.  
Elapse time : Displays the elapsed time from starting measurement in Elapse time.
- Data at click point : Click peak point of the spectrum and then turn the color to green and display the ion current, partial pressure and concentration at that point.
- Y-axis min/max setting : Sets the minimum and maximum value of the Y-axis by using the arrow key.
- Scroll back bar : Enables display of old data by scrolling back. To display the latest data, drag the scroll button to the right end position.
- Display trend data : Enables display of trend for required mass number in the Scan mode by setting toolbar group C (3). Refer to "3.6 Display setting dialog (scan / Analog mode) trend tab" for more information about setting. The trend graph display ratio can be switched over from "1/2", "1/3", "1/4", "1/5" and "no display" in that order with the tool bar group C (5).
- Display of data in bar cursor position : Data in the bar cursor position on the trend graph is the bar graph displayed data and the data of the peak selected on the bar graph is displayed numerically at the left of the bar graph. If the bar cursor is in the position of the latest data during measurement, the measurement data is displayed and updated in real time. If the bar cursor is in the past (intermediate) data position, display of the data in the bar cursor position continues regardless of updating the measurement data (latest data).

## 3.5.2 Trend mode/He leak test mode





Fig. 3.12 Trend mode/He leak test mode screen

1. Display legend
2. X-axis setting

# LEYSPEC software functions



1. Data in bar cursor position
2. Display bar data

X- axis setting : Sets the display range of time for the X axis.

Display legend : Displays the value of the ion current, partial pressure and concentration for each mass number. Select display or non display is enabled by using toolbar group C (4).

Display bar data : Enables the display bar to display the required mass number in the Trend / He leak test mode by setting toolbar group C (3). Refer to "3.6 Display setting dialog (trend mode / He leak test mode) bar tab" for more information about setting. The bar graph display ratio can be switched over from "1/2", "1/3", "1/4", "1/5" and "no display" in that order with the tool bar group C (5).

Display of data in bar cursor position : Data in the bar cursor position on the trend graph is the display data of the bar graph and the numerical data of the legend.

## 3.5.3 Analog mode




Fig. 3.13 Analog mode screen

## 3.5.4 Sensitivity calibration mode




Fig. 3.14 Sensitivity calibration mode screen

### 1. Calibration setting value

Calibration setting value : Displays the setting value of the sensitive calibration with a red solid line and the permissible value for the setting value with a red dotted line.

# LEYSPEC software functions

## 3.5.5 Degas mode




Fig. 3.15 Degas mode screen

- Start : Start to degas.
- Status : Displays filament, degas mode (SLOW, FAST), processing time, elapsed time, etc.
- Remaining time : Displays remaining time of degassing.
- Emission current : Displays emission current in degassing.

## 3.5.6 Display setting dialog




Fig. 3.16 Scan mode/analog mode

- X&Y axis : Sets the display range of the X and Y axis to display the data.
- Color : Sets the display color of data, background, etc. You can select a particular color by double clicking the displayed color.
- Date & time : Sets the time to display the data. Moves to the latest data position when "Latest" is checked.
- Trend : Sets display trend part in scan mode. Can change the width of the trend display part by "Width of display". Checking [B] displays only the channel (Ch) with a thick line. Thick line display is not reflected in the printout result.

# LEYSPEC software functions



Fig. 3.17 Trend mode/He leak test mode

- X&Y axis** : Sets the display range of the X and Y-axis to display the data.
- Color** : Sets the display color of the data, background, etc. You can select a particular color by double clicking the displayed color.
- Checking [B] displays only the channel (Ch) with a thick line. Thick line display is not reflected in the printout result.
- Displays the marker at the right side of the Y-axis of the setting value for abnormal or warning partial pressure that is set on Ch when [SP] is checked.
- Total pressure** : Set to display in measuring total pressure. This is not displayed when the measurement is not set by the recipe. Only displays data when "Display" is checked.
- Analog ch1,2** : Same function as the above-mentioned "Total pressure".
- Display is enabled only when the analog has been selected from the recipe.
- PP-Ratio 1,2** : This function is the same as that of the above total pressure tab. Display is enabled only when the ratio has been selected from the recipe (only Trend Mode).

Bar : Set to display bar part in trend / He leak test mode. You can change the width of the bar display part by "Width of display". Only the data with a check mark is displayed by bar graph. The bar graph color is the same as the trend display color.

### 3.6 Displaying gas names of mass number

Displays the gas name on the graph instead of the mass number. Printed result is also the gas name.

The gas name is set by clicking "Setting" → "Set gas name" of the menu.




Fig. 3.18 Gas name setting screen

Mass No. : The mass number is displayed. It cannot be changed.  
Gas Name : The gas name corresponding to the mass number is displayed. It can be changed within six character length.  
Initialization : The gas name display is returned to mass number display.

---

#### NOTICE:

*The data file does not store the gas name information. If the gas name saved in the data file and the currently set gas name differ, the gas name display of the loaded data file will be the current gas name.*



# LEYSPEC software functions




Fig. 3.19 Trend graph of scan mode




Fig. 3.20 Trend and bar graph of trend mode

## 3.7 Baseline subtract

The ion current of  $m/z=10$  can be considered as a baseline of measurement because gas with a mass number of  $m/z=10$  does not exist. To reduce minimum detectable partial pressure, LEYSPEC RGA software has a function which subtracts the ion current of  $m/z=10$  from each measured ion current. Switching On/Off of this function can be set from menubar [Menu → Setting → BaseLine Substract]. This function is available only when the recipe is trend mode and its vertical axis is set to partial pressure. When using this function, measurable gas species is set to 19 species maximum, because  $m/z=10$  is set to Ch20 automatically.

## 3.8 Mass number calibration by analog mode

The measurement mode of trend and scan obtains data after selecting and scanning within the analog spectrum or the vicinity of the peak top. Therefore, it is necessary to recognise a peak top position of an analog spectrum to an appropriate number of mass. This is done by analog mode.

### 3.8.1 Confirmation of analog spectrum

- Create and send a recipe of the analog mode.
- Click "FIL" → "MES" icon and then start measuring the analog mode.
- Verify an analog spectrum as seen in on page 38.




Fig. 3.21 Analog spectrum confirmation

### 3.8.2 Set or delete peak top position

- Terminates the measurement.
- Displays a green line when the required peak top position is selected and clicked on via the left button. The dialog is displayed when the right button is clicked on. (The example assumes a peak top position of  $m/e=28$ .)




Fig. 3.22 Calibration point screen

# LEYSPEC software functions

- Verify the mass number is correct and click [OK] to relate the peak position with the mass number on the software.
- To delete peak position that is related with the mass number, left click on the peak position of the displayed mass number and then right click on it. The following dialog box will be displayed to allow deletion of the mass number:




Fig. 3.23 Calibration point deletion screen

### 3.8.3 Send peak top position (mass number calibration)

- Click "File" → "Send Calibration data" after completing the procedure (6-2) for the required mass number (refer to on page 39) and send the setting value of the mass number calibration to the sensor.

When a set value is transmitted to the sensor, it is necessary to input a set point of three points or more.

- Interpolate and extrapolate data for the peak that is not related to the peak position to relate with the mass number.




Fig. 3.24 Send peak top position

# LEYSPEC software functions

## 3.8.4 Save and open mass number calibration data

You can save the result of the mass number calibration data on the PC. Save with the file name \*\*\*\*.cal by clicking "File" → "Save Calibration data". After reading this file, click on "File" → "Open Calibration data" and proceed as (6-3) to send saved calibration point data to the sensor.

## 3.9 Sensitivity calibration mode

Calibrate the sensitivity of the SEM so that the set constant ion current value is obtained.

This is effective except when the connected sensor is not LEYSPEC view100/ LEYSPEC view200.

Select [Calibration by reference gas] or [Calibration by SEM gain].

The screenshot shows a software window titled "New Recipe for Sensor 1". It contains several input fields and radio buttons for configuring a sensor recipe. The "Sensor Type" is set to "LEYSPEC view 100S". The "Mode" is set to "Calibration". The "Ionization voltage" is set to 50, and the "Sweep Speed" is 200 msec/AMU. The "Unit of Y axis" is set to [A]. Under "Ref. to partial pressure", "Calibration value" is selected. Two calibration methods are shown: "Calibration by reference gas" (selected) with Mass number 28, Calib. pressure 1.00e-05 mbar, and Calib. current 1.00e-10 A; and "Calibration by SEM gain" with Mass number 18 and Gain 10000. Buttons for "Apply", "Save", and "Cancel" are at the bottom.

Fig. 3.25 SEM sensitivity calibration

# LEYSPEC software functions

## 3.9.1 Processing flow of [Calibration by reference gas] mode



Fig. 3.26 Processing flow of [Calibration by reference gas] mode

## 3.9.2 Saving the log of calibration result in sensitivity calibration mode [Calibration by reference gas]

The software saves the information at the end of calibration in the sensitivity calibration mode in the text file (Adjust#.txt: # is the sensor No.). The number of logs that can be saved is unlimited.

# LEYSPEC software functions

---

## NOTICE:

This software has no function for viewing the log of sensitivity calibration results. To check the log, use a memo pad, Microsoft Excel or other. To check it, exit this software or the sensitivity calibration mode.



```
Adjust1.txt - Notepad
File Edit Format View Help
"Calib. date", "Time", "Mass No.", "Calib. press. [Pa]", "Calib. current[A]", "SEM voltage at end[kV]"
"2005/05/12", "11:48:05", 2, 1.00E-005, 5.00E-008, -1.030
"2005/05/12", "11:51:21", 28, 1.00E-005, 8.00E-008, -1.090
"2005/05/12", "12:57:03", 2, 1.00E-005, 5.00E-008, -1.120
```


Fig. 3.27 Log view

- |                                       |  |
|---------------------------------------|--|
| Date of sensitivity calibration       | : Saves the date on which sensitivity calibration was completed.                                       |
| Time                                  | : Saves the time when sensitivity calibration was completed.   |
| Measurement mass number               | : Saves the Mass number set with "(Create Sensitivity Calibration recipe) in (3-1) Create recipe".     |
| Sensitivity calibration pressure [Pa] | : Saves the Calib. Pressure set with "(Create Sensitivity Calibration recipe) in (3-1) Create recipe". |
| Set ion current value [A]             | : Saves the Calib. Current set with "(Create Sensitivity Calibration recipe) in (3-1) Create recipe".  |
| SEM voltage at end [kV]               | : Saves the SEM voltage value at the end of sensitivity calibration.                                   |

# LEYSPEC software functions

## 3.9.3 Processing flow of [Calibration by SEM gain] mode

CS/1909/A



To the next page



Fig. 3.28 Processing flow of [Calibration by SEM gain] mode

### 3.9.4 Saving the log of calibration result in sensitivity calibration mode [Calibration by SEM gain]

Saves the information at the end of calibration in the sensitivity calibration mode in the text file (Adjust\_BySEMGain#.txt: # is the sensor No.). The number of logs that can be saved is unlimited.

#### NOTICE:

This software has no function for viewing the log of sensitivity calibration results. To check the log, use a memo pad, Microsoft Excel or other. To check it, exit this software or the sensitivity calibration mode.



# LEYSPEC software functions

Calib. date	Time	Mass No.	FC Ion Current[A]	TP during FC[Pa]	SEM Ion Current[A]	TP during SEM[Pa]	Setting Gain	SEM voltage at end[kV]
2016/11/17	"10:17:04"	18	1.00E-010	1.00E-005	1.00E-007	1.00E-005	1000	-1.500
2016/11/17	"10:37:03"	18	1.00E-010	1.00E-005	1.00E-007	1.00E-005	1000	-1.500

cs/2056/A

Fig. 3.29 Save the calibration log

- Calib. date : Saves the date on which sensitivity calibration was completed.
- Time : Saves the time when sensitivity calibration was completed.
- Mass No. : Saves the Mass number set with "(Create Sensitivity Calibration recipe) in (3-1) Create recipe".
- FC Ion Current[A] : Saves the ion current (FC).
- TP during FC[Pa] : Saves the total pressure during FC.
- SEM Ion Current[A] : Saves the ion current (SEM).
- TP during SEM[Pa] : Saves the total pressure during SEM.
- Setting Gain : Saves the gain value set with "(Create Sensitivity Calibration recipe) in (3-1) Create recipe".
- SEM voltage at end [kV] : Saves the SEM voltage value at the end of sensitivity calibration.

## 3.10 FIL/SEM ON integrated time display

Acquires the time for which FIL and SEM are lit (ON) from the sensor and displays it as a guide for the life expectancy of the FIL/SEM.

The integrated FIL1/FIL2/SEM ON time is displayed in hours on the Control Panel dialog. The latest integrated time is displayed when the Control Panel dialog is opened. Keeping the dialog open does not update the display of the integrated time.




Fig. 3.30 FIL/SEM display

- FIL1 (FIL2) : Displays the FIL1 ON integrated time in hours when filament 1 is selected, and displays the FIL2 ON integrated time when filament 2 is selected. It cannot be changed.
- SEM : Displays SEM ON integrated time in hours. It cannot be changed.
- FIL reset : Initializes the selected filament ON integrated time to zero.
- SEM reset : Initializes the SEM ON integrated time to zero.

---

**NOTICE:**

If the [Reset] button is clicked and the ON integrated time is initialized, control cannot be returned to a time before initialization. Reset it immediately after replacing the FIL/SEM.



### 3.11 Local mode setting

The local mode setting takes measurements using the dip switch on the sensor side without connecting to the PC (local mode) and the function of taking measurements through communication with this software (remote mode) can be changed over.

Set the conditions necessary for making measurement in the local mode here.

#### 3.11.1 Setting the mass number

Sets the mass number on the [ANY] button on the sensor side.

The mass number is set by clicking "Local Mode Setting" → "ANY mass number" from the menu.

(This menu cannot be selected if the sensor is connected to a measurement being made or the loaded data is displayed.)




Fig. 3.31 Set mass number screen

- ANY mass number : Sets the mass number to be allocated to the [ANY] button.  
It is 44 as default. The range that can be set varies with the connected sensor.
- [OK] button : Clicking the [OK] button sends the set mass number to the sensor.

#### 3.11.2 Setting the sensitivity factor

Sets the factor to calibrate the sensitivity of the partial pressure value to display on the indicator on the sensor side.

# LEYSPEC software functions

Setting a factor gives commonality to the partial pressure data in the local mode and in the remote mode.

## Setting the FC sensitivity factor

The sensitivity factor is set by clicking "Local Mode Setting" → "Sensitivity Factor" from the menu.

(This menu cannot be selected if the sensor is connected to measurement being made or the loaded data is displayed.)




Fig. 3.32 Set the FC sensitivity factor screen

- pressure : Value common with the pressure of "5. Others (1-4) Calibrate Sensitivity of FC".
- Ion current : Value common with the ion current of "5. Others (1-4) Calibrate Sensitivity of FC".  
The range that can be set is 1.00E-5A to 1.00E-14A.
- [OK ] button : Click the [OK] button to send the set factor value to the sensor.  
<Factor calculating formula>  $S = P / I$   
S : Factor value of FC  
P : Pressure  
I : Ion current

## Setting the SEM sensitivity factor

Sends the factor value to the sensor immediately after the sensitivity calibration mode has terminated normally.

<Factor calculating formula>  $S = P / I$

S : Factor value of SEM

P : Calibration Pressure

(Calib. Pressure set with "(Create Sensitivity Calibration recipe) in (3-1) Create recipe".)

I : Mean value of data when sensitivity calibration ends normally

Please refer to "4. Details (7-1) Processing flow of the sensitivity calibration mode \*1)" for the process to send factor values to the sensor.

## 3.12 SEM interlock function

To meet the conditions necessary for <SEM interlock function essential condition>, "Over SEM interlock value" dialog appears after stopping measurement and OFF SEM if total pressure measurement value is over interlock setting value. However, if it is shut down by SEM interlock in Automatic measurement mode, the message "Over SEM interlock value" is not shown.

To set up the SEM interlock connect a LEYSPEC view100S/200S or LEYSPEC Ultra200S/300S. The SEM interlock is set by clicking "Sensor" → "SEM interlock setting" from the menu.




Fig. 3.33 SEM interlock setting screen

Active : Set if the SEM interlock function is enabled or removed.

Interlock value : Set SEM interlock pressure value.

(Default setting is LEYSPEC view100S/200S : 1e-2Pa,  
LEYSPEC ultra : 3e-3Pa)

<SEM interlock function essential condition>

- Select SEM from the "Ion Collector" group from the "Control Panel" dialog.
- Put a check mark on the SEM at the "Operation setting of FIL button" group of the "Control Panel" dialog.

(It is necessary to synchronise measurement motion and SEM ON/OFF motion.)

- Put a check mark on Active at the "SEM interlock setting" dialog.

# LEYSPEC software functions




Fig. 3.34 SEM interlock function essential condition screens

### 3.13 Procedure for abnormal partial pressure and warning

Turn the lamp of the toolbar group B (9) and (10) on and relate an error or warning when partial pressure error and warning of "(3-1) Create recipe" is set in trend/He leak test mode.



Fig. 3.35 Toolbar B screen

The dialog in on page 50 will be displayed by clicking "Sensor" → "Output of error & warning" and will enable verification of abnormal partial pressure and warning output for each mass number.

Click the "Error" button in the "Stop Output" group and then reset the error output and output from the I/O in the control unit. Click on the "Warning" button for the same result.




Fig. 3.36 Output of error and warning sensor 4 screen

After resetting, the error and warning output decision processing is not performed during the measuring action.

Please refer to the operation manual for hardware for output specification for error or warning output of the sensor.


### 3.14 Analyzer protecting function

- This function prevents the failure of the analyzer tube that may be caused by corrosive halogen type gas.
- If a specific mass number exceeds the threshold value, a warning is displayed in the software window.
- If the integral value (ion current value multiplied by time) exceeds a set value, the voltage applied to the filament/secondary electron multiplier tube is automatically turned off.
- This function can be used only in the scan mode or trend mode when operated from a PC.

#### 3.14.1 Setting the analyzer tube protecting function

The setting window can be opened from [Sensor] → [Analyzer Protection Function]. It can be opened in the scan mode or trend mode when the sensor is connected and measurement is not being made.

# LEYSPEC software functions



[1] Setting channel

Mass number can set up to 20 channels.

[2] Mass number

Mass number to see the alarm and FIL/RF/SEM off function is selected.

[3] Gas name

If the gas name is set in the table, the name is displayed instead of mass number. Refer to "4. Details (5) Displaying gas names of mass number" for the method of setting the gas name.


[4] Warning ion current (FC)

If the actual measured ion current value becomes higher than the set threshold value, the warning display appears in the software window. If the actual measured ion value becomes smaller than the threshold value, the warning display goes off.

[5] Warning ion current (SEM)


Refer to this value when SEM mode has been selected. If the actual measured ion current value becomes higher than the set threshold value, the warning display appears in the software window. If the actual measured ion value becomes smaller than the threshold value, the warning display goes off.

# LEYSPEC software functions



## [6] FIL/RF/SEM off integrated value

Set the threshold value of the integrated value to turn off FIL/RF/SEM. If the actual measured integrated value becomes higher than the set threshold value, the warning display appears in the software window and measurement stops, the filament is turned off and the SEM (only models equipped with a SEM) stops.



## [7] Actual measured integral value

Integral value of the mass numbers set with [2].

The integral value is calculated from the ion current value up to the point where measurement was stopped by the operator, an error stop due to the integrated value of specific gas, or by other errors and updates to the table.

The calculation equation:

$$S = T \times \sum I_m$$

S: Integral value (A sec)

T: Measurement time (sec)

$I_m$ : Ion current value of specific gas (A)

$\sum I_m$ : Total sum of ion current values of mass number m up to measurement stop (A)

## [8] Measurement mode to use

Selects the measurement mode of this function.

## [9] Warning valid/invalid setting

Selects whether the warning display function by ion current value is valid or not.

# LEYSPEC software functions

[10] Automatic measurement stop function valid/invalid setting

Selects whether the function of automatic measurement stop by ion current value is valid or invalid.

[11] Integral value resetting

Resets the actual measured integral value.

[12] OK/cancel

Press the OK button to validate the set value.

- The mass number, set value and integral value are recorded in the sensor.
- The mass number, set value and integral value are sent to the sensor when a sensor shuts off.
- When the sensor is connected, the mass number, set value and integral value are read from the connected sensor and are read and reflected in the setting.




Fig. 3.37 Default setting screen

- The mass number, set value and integral value are saved along with the measurement data (scan data, trend data).
- The warning can be displayed, measurement can be stopped and the integral value can be updated with the set threshold value, also when partial pressure is selected on the vertical axis.




Fig. 3.38 Operational flow

## 3.15 Correcting an error

Take action to correct an error when the sensor is faulty or when the external/internal interlock is actuated.

### 3.15.1 Error correcting action

The following is a sequence of actions to be taken when FIL/RF/SEM is faulty or when the total pressure (internal/external) interlock is actuated.

#### When host communication function is disabled (standard function)

1. If measurement is underway, it stops.
2. FIL/RF/SEM are turned off.
3. The warning state is displayed. (13-2)

# LEYSPEC software functions

## When host communication function is enabled

---



### NOTICE:

The host communication function is optional. It cannot be used by the standard function.

---

- When an error has occurred somewhere other than during trend mode measurement.

The same action as (13-1-1) is taken.

- When error has occurred during trend mode measurement.
  1. The data values for graphic display and for host communication are held and actions [2] - [4] are taken to reset FIL/RF/SEM fault (reset action).
  2. FIL/RF/SEM are turned off.
  3. FIL/RF/SEM are turned on five seconds later.
  4. Data acquisition restarts five seconds later.
  5. If the faulty or interlock state continues even after the resetting actions ([2] - [4]) are taken three times, actions [6] to [8] are taken.
  6. Measurement stops.
  7. FIL/RF/SEM are turned off.
  8. The warning state is displayed. (13-2)

## When measurement motion is in automatic measurement mod

---



### NOTICE:

Automatic measurement mode is an optional function. It cannot be used by the standard function.

---

- When only total pressure (internal) interlock or external interlock occurred (with automatic return function)
    1. If measurement is underway, it stops.
    2. FIL/RF/SEM are turned off if they are on.
    3. The warning state is displayed in another window.
- 



### NOTICE:

Other processes can be carried out with warning state displayed.

---

4. [FIL] and [MES] buttons are still disabled display.
5. Display still enabled with [Remote] button pushed.

# LEYSPEC software functions

6. Stops the confirmation process of automatic measurement start condition and importing pressure value of analog ch1 input.
  7. Continues to watch the states of total pressure (internal) interlock and external interlock (about a 5-second interval).
  8. The warning state is closed automatically if it is still displayed when total pressure (internal) interlock and external interlock are cancelled.
  9. Restarts the confirmation process of the automatic measurement start condition and importing the pressure value of the analog ch1 input after the total pressure (internal) interlock and external interlock are cancelled. The measurement is started when the automatic measurement start condition continues until the delay time of the measure start passes. (Automatic return)
- When any FIL/RF/SEM abnormalities occurred.
    1. If measurement is underway, it stops.
    2. FIL/RF/SEM are turned OFF if they are ON.
    3. The warning state is displayed (13-2).
    4. [FIL] and [MES] buttons are still disabled on the display.
    5. It changes to disabled display when [Remote] button is pushed.
    6. Stop confirmation process of automatic measurement start condition and importing pressure value of analog ch1 input.

## 3.15.2 Warning state display




Fig. 3.39 Warning state display

- |               |   |  |
|---------------|---|--|
| Filament      | : | Lights up when the emission current of the ion source is not controlled correctly because of a cut off filament or any other cause.  |
| SEM           | : | Lights up when the SEM has an error.   |
| RF            | : | Lights up when the tune is incorrect between the analyzer and the RF unit or there is a problem.   |
| T.P. (inside) | : | Lights up when the total pressure measurement value has exceeded the total pressure interlock setting value.<br>(Setting value is determined by clicking "Sensor" → "T.P. interlock setting" from the menu. It works only when "active" is checked.<br>(Default setting is LEYSPEC view : 1e-2Pa, LEYSPEC ultra : 3e-3Pa)) |

# LEYSPEC software functions




Fig. 3.40 Interlock setting

External : Lights up when the set point is over during the reading output of the setting point for the external vacuum gauge.

### 3.15.3 An error has occurred

When measurement motion is in automatic measurement mode and only total pressure (internal) interlock or external interlock has occurred, nothing is operated during the automatic return operation until total pressure (internal) interlock or external interlock is canceled.

When the filament burnout etc. causes these errors, push the OK button of the "Output of Error & Warning Sensor#" dialog and execute the following procedure:

1. Confirm the cause that generates the error and fix the cause.
2. Reset the LEYSPEC LEYSPEC RGA power supply.
3. If measurement motion is in manual measurement mode, push the FIL button again with the software, and confirm the LEYSPEC RGA hardware including the analyzer works normally.

In automatic measurement mode, confirm if LEYSPEC RGA hardware including analyzer works normally in the software by pushing the [FIL] button after pushing the [Local] button. If it functions normally, press the [Remote] button.

### 3.16 Communication error

Communication error correcting action is taken if an error has occurred in communication with the LEYSPEC RGA power supply.

#### 3.16.1 Communication error correcting action

The following is a sequence of actions after a communication error has occurred.

#### When host communication function is disabled (standard function)

1. Communication error corrective actions are taken against [2] and [3] from the first error (total 3 times, that is, 3 re-trials per error).
2. If measurement is underway, it stops.
3. Communication error message is displayed.

## When host communication function is enabled

---

### NOTICE:

The host communication function is optional. It cannot be used by the standard function.



- When an error has occurred in another mode other than trend mode measurement

The same action as (13-1-1) is taken.

- When an error has occurred during trend mode measurement
  1. Data for host communication holds the data value immediately before without updating the graph display and measurement action continues without taking corrective actions against the communication error. Communication error corrective actions in [2] and [3] are taken four times consecutively (total 12 times, that is, 3 re-trials per error).
  2. Measurement stops.
  3. Communication error message is displayed.

## When measurement motion is in automatic measurement mode

1. If measurement is underway, it stops.
2. Communication error message is displayed.
3. [FIL] and [MES] buttons are still a disabled display.
4. It changes to a disabled display when the [Remote] button is pushed.
5. Stop confirmation process of automatic measurement start condition and importing pressure value of analog ch1 input.

### 3.17 Save data

#### 3.17.1 < Extension to save data >

The extension to save data is determined as follows by the measurement mode. The data is saved with binary but it is possible to re-save CSV (file extension:\*.CSV) by clicking "File" → "Save by text form".

scan mode	: qss
trend mode / He leak test mode	: qst
analog mode	: qsa

# LEYSPEC software functions

## 3.17.2 < Difference of saving method difference >

- Depending on whether the type of data saving is [AutoSave] or [Confirmation] and when in the scan / trend / He leak test mode measurement, data from the measurement start to stop are saved in a batch. In the analog mode measurement, only the data displayed on the screen is saved.
- When the type of data saving is [at Sampling] and in the scan/trend/He leak test mode measurement, data is saved at each measurement sampling.



### NOTICE:

If the disk capacity is full during measuring in every sampling, the measurement will crash and no data will be saved. It is necessary to make free space to prevent crashes.

---

## 3.17.3 < Save data size >

Example:

Measurement condition is

Scan mode is selected, measurement speed is 200 ms, auto is selected for measurement interval, mass number range is from 2 to 200, measurement time is 6 hours. The file capacity would be 432 kB.

## 3.17.4 < Notes to save data >

- When the type of data saving is [AutoSave] or [Confirmation] and in the scan/trend/He leak test mode measurement or in the analog mode measurement, the measurement data of this software is stored in the PC memory and is saved in a batch when measurement is stopped. In this case, if the PC hangs up during measurement, the measurement data will not be retained. Therefore, use it in a stabilised PC environment. Always save the data or, if measurement is made continuously for an extended time, selecting [at Sampling] is recommended.
- Measurement data does not remain after shut down of measurement operation during sleep mode on a laptop, computer etc. You must cancel sleep mode.
- When exclusive memory for this software on a PC becomes full during long term measurement, stop measurement automatically and save data to a file and then restart measuring. The saved file is named automatically on the PC, same as the above procedure "(3-1) Create recipe".
- Every hour after starting up and shortly after starting up, check the free space of the data destination disk in sensors 1 through 8.



### NOTICE:

If free space is less than 10% of total capacity, the following warning dialog box appears. If this warning dialog box appears, it is necessary to make free space by implementing measures given in the dialog box.

---




Fig. 3.41 Residual Gas Analyzer dialog box

### 3.18 Display and print saved data

Click "File" → "Open" to open and "File" → "Print" to print saved data, same as standard Windows software.

When the trend/He leak test data is printed, the width of the line for each CH can be set by clicking "trend display set" → "width of the line" in the "(4-6) Display setting dialog".

### 3.19 Setting the T.P. coefficient

Sets the coefficient to correct the distortions between the T.P. measured from the Residual Gas Analyzer and the pressure of the chamber device. The T.P. coefficient can be set by clicking the menu "Sensor" → "T.P. coefficient setting" after connecting the sensor.

### 3.20 Alarm log

If any of the following alarms occur, the log of the alarms that occurred on the same day are displayed in a pop-up.

1. Partial pressure error/alarm
2. Filament/RF/SEM error
3. Total pressure interlock
4. External pressure interlock
5. SEM interlock
6. Total pressure set point
7. Analyzer protecting function
8. Communication Error
9. Disk Full

The display can also be enabled from "Display" → "Alarm Display" from the menu after the sensor is connected. The log is saved daily in a file.

Saving file: InstallationFolder\AlarmLog\

## 4 Others

### 4.1 Menu before connecting the sensor

Before connecting the sensor, go through the setting items in the "Setting" menu .

#### 4.1.1 Communication setting [IP address, COM port]

Set the communication of the PC to use this software.




Fig. 4.1 Communication setting

A. Standard function screen

B. Host communication function screen

"IP Address" group : Sets the IP Address to communicate with the sensor.

"Host COM port" group : Sets the COM port for communication with the host software (host). Select the COM port from the list.

#### NOTICE:



The host communication function is optional. [Host COM port] cannot be set by the standard function.

The host communication's speed is 9600 bps. It cannot be changed.

#### 4.1.2 Setting the communication log file

Enter the execution condition of the real time storing of the communication command send and receive history.




Fig. 4.2 Communication log file setting

A Standard function screen

B. Host communication function screen

"Sensor"group : Enter the execution condition of storing the sensor communication log.

When "Log Save" is selected, the communication log is stored in the log file. See < [Naming rule of the log file](#) > on page 63.

The log file is stored in the CommLog folder.

### 4.1.3 < Naming rule of the log file >

Q\_Ssn\_YYMMDD\_NN.TXT

Ssn : S is a fixed character.

sn is the sensor number 1 to 16 connected.

sensor number 1 = S1.

sensor number 16 = S16.

YY : Indicates the year (for example, 2018 = 18)

MM : Indicates the month (for example, January = 01)

DD : Indicates the day (for example, from 1 to 9, 1 = 01)

The new file is created, when the date is updated.

NN: Two digits of the serial number

The log file is divided by every 1.4 MB, and the serial number is incremented by one.

If the log file capacity is less than "The maximum capacity of log folder [MB]", the new log file is created in the log storage folder.

If the log file capacity is over "The maximum capacity of log folder [MB]", the oldest log file is deleted and the total capacity of the log file is adjusted within the limit.

"The maximum capacity of log folder [MB]" must be less than 10% of empty capacity of the drive in which this software is installed.

When "Log NoSave" is selected, the communication record is not stored.

"HOST"group : When Host communication (optional) is effective, enter the execution condition of the Host communication log.

When "Log Save" is selected, the communication log is stored in the log file, see < [Naming rule of the log file](#) > on page 63.

The log file is stored in the HostCommLog folder.

#### 4.1.4 < Naming rule of the log file >

H\_YYMMDD\_NN.TXT

The rule is the same as the sensor side.

The limitation of the maximum capacity and "Log NoSave" setting are the same as the sensor side.



#### NOTICE:

The host communication function is optional. It cannot be used by the standard function.

#### 4.1.5 Calibrate the sensitivity of the Faraday cup (FC)

Set the conversion value to convert the measurement value to partial pressure by measuring the Faraday cup.




Fig. 4.3 Sensitivity calibration



#### NOTICE:

When partial pressure is displayed by the reference to the sensitivity proofreading value, it is necessary to set ion current value minus partial pressure value beforehand when partial pressure with a Faraday cup is measured. When this set value is decided, a single gas (N<sub>2</sub> and Ar, etc.) is introduced into the vacuum device to become constant pressure, and the vacuum meter instruction value and the ion current value of QMS (N<sub>2</sub>=28 and Ar=40, etc.) is measured.

#### 4.1.6 Setting the Argon coefficient

The Argon coefficient is set when you adjust the partial pressure calculation of measurement at the time of M/e=40 and M/e=36. To satisfy all conditions of <Indispensable condition for Argon pseudo display>, multiply setting coefficient (Argon isotope abundance 40Ar/36Ar) by real value of M/e=36, and M/e=40 is pseudo data. The coefficient is set by clicking "Setting" → "Set Ar coefficient" from the menu before connecting the sensor.




Fig. 4.4 Setting Ar coefficient

Argon coefficient : Setting range is from 0 to 500.

If 0 is set as a coefficient, calculate partial pressure with an actual measured ion current value of M/e=40.

If a numerical value except 0 is the set Argon coefficient, M/e=40 is not actually measured. Calculate partial pressure with the value that multiplies the Argon coefficient by actual measured value of M/e=36, making an ion current value of M/e=40.

<Partial pressure calculation formula>

$$P_n = TP * I_i / (I_i + (I_{36} * \text{Ar coefficient}))$$

$P_n$ : Partial pressure value of measurement mass number.

TP: Total pressure value.

$I_i$ : Ion current value of measurement mass number.

$\sum I_i$ : Summation of ion current value of measurement mass number.

$I_{36}$ : Ion current value of M/e=36.

#### 4.2 Measuring with a Faraday cup (FC)

There are some differences between using a SEM and measuring by Faraday cup.

- Sensitivity calibration in FC measurement

In the FC measurement, set the above procedure "Calibrate sensitivity of FC" to display partial pressure on based sensitive calibration value.

- Switch of SEM · FC in LEYSPEC view/LEYSPEC Ultra

When the measurement is started just after the connection is changed from LEYSPEC view 100/200 to another model, FC is kept for setting the detector. To

measure with the SEM, check "SEM" from Setting for FIL performance at "Control panel" and also check "SEM" for "Detector".

### 4.3 Uninstall the LEYSPEC software

Uninstall this software as described in [< Uninstalling procedure >](#) on page 66.

Before the uninstall process, back up all data files you wish to retain so that you can reinstall or update the software.

#### 4.3.1 < Uninstalling procedure >

### Windows

"Start" → "Setting" → "Control Panel" → "Add or Remove Programs" → "Residual Gas Analyzer" → "Remove"

### 4.4 Glossary of terms

Sensor	: The analyzer of the quadrupole mass spectrometer (QMS) is indicated in the manual. The QMS is only for use with its corresponding control unit.
RF unit	: Unit to connect directly to or in the proximity of the analyzer.
Filament	: Filament for the analyzer. To avoid cutting off the filament, do not exceed an atmosphere of $1E-2$ Pa or more.
SEM	: Secondary electron multiplier tube.
Ionized voltage	: Voltage to ionize gas. The voltage is generally 40 V, 50 V or 70 V. When ionized voltage is lower, the ion dissociation could decrease in ionization.
Emission current	: Current flowing into the grid from the filament.

**4.5 Residual Gas Analyzer operation flow**




Fig. 4.5 Residual Gas Analyzer operation flow

# Analyzing a function after loading the data file

## 5 Analyzing a function after loading the data file

### 5.1 Processing the background

Subtracts the background from all data using the designated data as background data.

Actuated after loading the trend mode data file.

If the data after subtraction is zero or a negative value, it is replaced with 1.00E-14.

Graph printing and data saving processing can occur after background processing.

To save data subjected to background processing, affix "\_BG" to the end of the default filename.

#### 5.1.1 Background processing flow




Fig. 5.1 Background processing flow

### 5.2 Integral processing


Conducts integral calculation of a designated range.

Actuated after loading the trend mode data file.

# Analyzing a function after loading the data file

The integral result can be saved in the text format. “\_IR” is affixed to the end of the default file name.

## 5.2.1 Integral processing flow



CS/1918/A

Fig. 5.2 Integral processing flow

## 5.2.2 Displayed content of integration result

The integration result is displayed as shown in [page 69](#).

# Analyzing a function after loading the data file




Fig. 5.3 Integration result display

## 5.2.3 Saved content of integration result

The integration result is saved in the text format as shown in on page 69.




Fig. 5.4 Integration result saved content display

# Host communication functions

## 6 Host communication functions

### 6.1 Overview

Trend mode measurement data can be sent through RS-232C communication when requested by the host computer.

The measurement mode that sends data is the trend mode only. Data cannot be sent in other modes.

---

#### NOTICE:

The host communication function is optional. It cannot be used by the standard function.



---

### 6.2 Detailed specifications of messages

Messages are all in the ASCII code. Checksum is added to both the sending and receiving side.

#### 6.2.1 List of commands

#	Content	Command	Command parameter	Response	Response parameter	Remarks
1	Data request	DA	Sensor No. 1 - 16	da	NON	NON: Not available
					ERR	ERR: Error
					Data	Data: See (2.3)
					E00 (E zero zero)	E00: Format error
2	Error return	-	-	er	SUM	Checksum error
					None	When incorrect command is received

#### 6.2.2 Data request message format

The data request message is a communication command that requests this software for data from the host computer. The message is made up of command, command parameter, checksum and delimiter.

A command is made up of two uppercase alphabets.

Refer to "(2-8) calculation of checksum" for checksum calculation.

The delimiter is denoted with <CR><LF>. This delimiter must always be added to a command as a terminal character. There is no command other than this.

Command message DA1B6<CR><LF>

# Host communication functions

## 6.2.3 Data request return message format (data message format)

### Standard mode

Data message is a measurement data communication message sent from this software for the data request command of the host computer. The data message is made up of response command, data, checksum and delimiter.

Response command (2 characters)	: da Header code for identification.
Sensor No. (1~2 character)	: 1 - 16 This software can control up to 16 sensors via one personal computer. It is a sensor identification number.
Unit (1 character)	: A (for ion current value), M (for concentration), P (for partial pressure [Pa]), T (for partial pressure [Torr]), B (for partial pressure [mbar])  * Partial pressure [Torr] or [mbar] is an optional function. It cannot be used by the standard function.  This software can select ion current value (intensity) [A], partial pressure value [Pa] (Or [Torr] or [mbar]) and concentration value [ppm] as units of data. It indicates the unit of transmission data.
CH data (18 characters)	: Mass number (000 to 300)  Measurement mass numbers are 001 to 300. Always denoted with 3 digits. The number of channel that is not measured is 000. It is 040 for Argon.  Data value (X.XXE XX)  Data value: The mantissa part is two digits below decimal point and E, followed by the symbol of exponent part and two digits of exponent part.  Setpoint alarm value (0000)  Setpoint alarm value: Indicated with 4 digits like 0000.  Abnormal value higher limit, alarm value higher limit, alarm value lower limit and abnormal value lower limit from left to right. 1 is set at the digit that exceeds the higher or lower limit of the setpoint. 0011 when the data is lower than the abnormal value lower limit. 0100 when abnormal value higher limit>data value>alarm value higher limit. Setpoint is a value set on the recipe of this software. The set value cannot be acquired through communication.
Checksum (2 characters)	: 00 - FF  Refer to "(2-8) calculation of checksum".
Delimiter (2 characters)	: <CR><LF>

### Example of data message

da1A,000,0.00E-00,0000,001,1.23E-01,0000,002,2.23E-01,0000,003,3.23E-01,0000,004,4.23E-01,0000,005,5.23E-01,0000,006,6.23E-01,0000,007,7.23E-01,0000,008,8.23E-01,0000,009,9.23E-01,0000,010,1.33E-01,0000,011,1.43E-01,0000,012,1.53E-01,0000,013,1.63E-01,0000,014,1.73E-01,0000,015,1.83E-

# Host communication functions

01,0000,016,1.93E-01,0000,017,2.03E-01, 0000,018,2.13E-01,0000,019,2.23E-01,0000AB<CR><LF>

\* Calculation of checksum in the example above is not correct.

## Compatible mode

Data up to 12CH is handled by this function. Data message is a measurement data communication message sent from the unit for a data request command of the host computer. The data message is made up of response command, data, checksum and delimiter.

Response command (2 characters)	: Da Header coder for identification.
Sensor No. (1~2 character)	: 1- 16 This software can control up to 16 sensors by one personal computer. It is a sensor identification number.
Unit (1 character)	: A (for ion current value), M (for concentration), P (for partial pressure [Pa]), T (for partial pressure [Torr]), B (for partial pressure [mbar]) * Partial pressure [Torr] or [mbar] is an optional function. It cannot be used by the standard function. This software can select ion current value (intensity) [A], partial pressure value [Pa] (Or [Torr] or [mbar]) and concentration value [ppm] as unit of data. It indicates the unit of transmission data.
CH data (18 characters)	: Mass number (000 to 300) Measurement mass numbers are 001 to 300. Always denoted with 3 digits. The number of channel that is not measured is 000. It is 040 for Argon Data value (X.XXE XX) Data value: The mantissa part is two digits below decimal point and E, followed by the symbol of exponent part and two digits of exponent part. Setpoint alarm value (0000) Setpoint alarm value: Indicated with 4 digits like 0000. Abnormal value higher limit, alarm value higher limit, alarm value lower limit and abnormal value lower limit from left to right. 1 is set at the digit that exceeds the higher or lower limit of the setpoint. 0011 when the data is lower than the abnormal value lower limit. 0100 when abnormal value higher limit>data value>alarm value higher limit. Setpoint is a value set on the recipe of this software. The set value cannot be acquired through communication.
Checksum (2 characters)	: 00 - FF Refer to "(2-8) calculation of checksum".
Delimiter (2 characters)	: <CR><LF>

# Host communication functions

## Example of data message

da1A,000,0.00E-00,0000,001,1.23E-01,0000,002,2.23E-01,0000,003,3.23E-01,0000,004,4.23E-01,0000,005,5.23E-01,0000,006,6.23E-01,0000,007,7.23E-01,0000,008,8.23E-01,0000,009,9.23E-01,0000,010,1.33E-01,0000,011,1.43E-01,0000AB<CR><LF>

\* Calculation of checksum in the example above is not correct.

## 6.2.4 Data request return message format (status response message format)

The status response message is a message that returns a status from this software for a data request command from the host computer. The response message is made up of response command, sensor no., parameter, checksum and delimiter.

Response command	: Da
(2 characters)	Header coder for identification.
Sensor No.	: 1- 16
(1~2 character)	This software can control up to 16 sensors via one personal computer. It is a sensor identification number.
Parameter	: NON: Not yet measured or under measurement in a mode other than the trend mode. ERR: SEM, RF, FIL or pressure (inside/outside) error is occurring. E00: When the number of received characters of the data request message is incorrect. erSUM: Checksum is not added to the data request message or checksum is incorrect. er: Data request message is incorrect.

- If a SEM, RF, FIL or pressure (inside/outside) error occurs when in the NON status (not yet measured or during measurement other than in the trend mode), NON will be sent with priority over ERR.
- If a SEM, RF, FIL or pressure (inside/outside) error occurs during trend mode measurement, ERR will be sent with priority.

Checksum (2 characters) : 00 - FF  
Refer to "(2-8) calculation of checksum".

Delimiter (2 characters) : <CR><LF>

Example of communication message:


da1NON12<CR><LF>

erSUM12<CR><LF> ' erSUM has no response command and sensor no.

\* Checksum calculation in the example above is not correct.


# Host communication functions

## 6.2.5 Data request command sequence



## 6.2.6 Exceptional processing

In this communication specification, receive time-out is 5 seconds. Receive time out means the time after the first character is received until delimiter is received. In case of time out, er is returned as with an incorrect command. Send time out is not provided.



## 6.2.7 Communication interval

The measurement interval of this software is maximum 1 second per sensor. It may not be able to communicate at a maximum speed of 1 second per sensor because of the performance of this software.

## 6.2.8 Calculation of checksum

Character is handled as byte (8-bit integer with no symbol).

The checksum of 1, 2, 3, 4, 5, 6, 7, 8 is calculated as follows:

$$0x31 + 0x2C + 0x32 + 0x2C + 0x33 + 0x2C + 0x34 + 0x2C + 0x35 + 0x2C + 0x36 + 0x2C + 0x37 + 0x2C + 0x38 = 0x02D8$$

Then the high-order one bytes (0x02) and low-order one bytes (0xD8) are added up.

$$0x02 + 0xD8 = 0x00DA$$

The two characters of the low-order two digits of 0x00DA are given as a character. Thus the checksum is DA.

# Host communication functions

"DA" is annexed to the end of the command.

## 6.2.9 Notes about function

1. Data is transmitted to the host only when in the trend mode measurement.
2. To start and end measurement, perform operation on this software personal computer. Communicating operation from the host cannot be performed.
3. If data is requested at an interval shorter than the measurement interval, the same data may be sent.

## 6.2.10 COM port setting

Set the RS-232C port for host communication with [Setting]-[Com port] in the menu when the sensor is not yet connected. Refer to "5. Miscellaneous (1) Menu before connecting sensor (1-1) Communication port" for more information.

The setting of the host communication should be the following settings:

Bits per second	: 9600 bps
Data bits	: 8-bit
Parity	: None
Stop bits	: 1-bit
Flow control	: None

## 6.2.11 Operation flow




Fig. 6.1 Operation flow diagram

## 7 Analog output function 1

### NOTICE:

The analog output function is optional. It cannot be used by the standard function. In addition, the board should be used with an analog output of "DA12-4(PCI)" or "DA16-8(LPCI)L".



### 7.1 Analog output

The data value of a specified mass number is output at each measurement interval in an analog form during trend mode measurement.

It is output by a linear signal of 0 to 10 V with respect to the specified amplifier range.

[Resolution of DA conversion]

DA12-4(PCI) is 12-bits.

DA16-8(LPCI)L is 16-bits.

Output of range data not more than  $1.0 \times 10^{-14}$  [A] is 0.0 V.

Other output voltages are determined by the measurement data value for the set amplifier range (set range is -5 to -14) or pressure range (set range is 1 to -10). That is, the output voltage value is a value divided by the set amplifier range (divided by  $1.0 \times 10^{-6}$  when the setting is -6).

If, for example, the amplifier setting is -6 and the measurement data value is  $1.5 \times 10^{-6}$  [A], 1.5 V is output. If the data exceeds  $1.0 \times 10^{-5}$  [A] at this time, 10 V will be output.

Ion intensity [A]	Output voltage [V] (when amplifier setting is - 6)
$1.0 \times 10^{-14}$ or more	0.0
.	.
.	.
.	.
$1.0 \times 10^{-7}$	0.1
.	.
.	.
.	.
$1.0 \times 10^{-6}$	1.0
.	.
.	.
.	.
$9.9 \times 10^{-6}$	9.9
$1.0 \times 10^{-5}$ or more	10.0

# Analog output function 1

## 7.2 Output state

Analog outputs are indefinite, except during trend mode measurement. For example, before startup of this software, immediately after startup, before measurement, after measurement and during measurement in other modes.

## 7.3 Setting analog output conditions

Select [Setting]-[Set analog output conditions] from the menu to set conditions.




Fig. 7.1 Set analog output conditions

Output ON/OFF : Sets whether or not the data value of the specified mass number is to be output in an analog form during trend mode measurement.

Output CH. : Sets the output channel number of the analog board.

Mass number : Sets a required mass number for analog output of data.

Range : Sets the range.

The setting amplifier range is -5 to -14.

The setting pressure range is 1 to -10.

## 8 Analog output function 2

### NOTICE:

The analog output function 2 is optional. It cannot be used by the standard function. In addition, the board should be used with an analog output of "DA16-8 (LPCI)L".



The analog output function 2 can be used with Sensor1 and Trend mode.

### 8.1 Analog output

<AO00~AO03>

The data value of a specified mass number is output at each measurement interval in an analog form during trend mode measurement.

It is output by a linear signal of 0 to 10 V with respect to the following formula:

$$V (\text{Output Voltage}) = \text{LOG} ( I[\text{A}] ) + 15$$

[Resolution of DA conversion]

DA12-4(PCI) is 12-bits.

DA16-8(LPCI)L is 16-bits.

Output of data not more than  $1.0 \times 10^{-14}$  [A] is 0.0 V.

If the data exceeds  $1.0 \times 10^{-5}$  [A] at this time, 10 V will be output.




Fig. 8.1 Analog output graph

# Analog output function 2

<AO04>

The sensor output status is as follows:

<b>Ion intensity [A]</b>	<b>Status</b>	<b>Output voltage</b>
AO04	Measurement	4.0V
	Idle	3.0V
	Unmeasured	2.0V
	Error	1.0V

## 8.2 Digital input

Signal can be input to trend mode and remote mode and during the connection of sensor1.

DI00 : Filament On/Off

DI01 : Measure Start/Stop

Select from the logic state of the signal.

- i. High : on when the high.
- ii. Low : on when the low



### NOTICE:

It is not possible to put the FIL OFF without a signal of MES OFF during measurement. In order to put the FIL OFF, MES OFF must be entered at the same time.

## 8.3 Digital output

DO00 : During the measurement

DO01 : Error

Select from the logic state of the signal.

- i. High : on when the high.
- ii. Low : on when the low.

## 8.4 Output state

Analog outputs are indefinite, except during trend mode measurement. For example, before startup of this software, selecting other sensors, immediately after startup, before measurement, after measurement and during measurement in other modes.

# Analog output function 2

## 8.5 Setting analog output and digital input/output conditions

The mass number cannot be entered and is not connected to the sensor.

Select [Setting]-[Set analog output conditions] from the menu to set conditions.




Fig. 8.2 Set analog output conditions

- Output ON/OFF : Sets whether or not the data value of the specified mass number is to be output in an analog form during trend mode measurement.
- Mass number : Sets a required mass number for analog output of data.
- FIL RF ON/OFF : High (on when the high) / Low (on when the low)
- Measure Start/Stop : High (on when the high) / Low (on when the low)
- During the measurement : High (on when the high) / Low (on when the low)
- Error : High (on when the high) / Low (on when the low)

# PLC communication

## 9 PLC communication

### 9.1 Overview



**NOTICE:**

The PLC communication function is optional. It cannot be used as a standard function.

---

When automatic measurement mode is selected, the TCP/IP communication to PLC is started during trend mode measurement. Automatic measurement mode is available only when trend mode measurement.

Inputs and outputs of PLC communication are:

[Input Item]

1. Hot cathode pressure, PV status
2. DV status
3. Device no., Lot ID

[Output Item]

1. Measurement Mass number
2. Partial pressure data, Total pressure data
3. Partial pressure set point
4. System error
5. Measurement status
6. Counter to check communication
7. Unit of Y axis

Input Item 1) : The pressure gauge that can be used by the sensor type is different.

When the hot cathode pressure value is less than "0.01 Pa" and PV status value is "1"(open), FIL/RF are turned on and start measurement. Otherwise, FIL/RF are turned off and stop measurement.

Input Item 2) : Refer to "(4) Setting partial pressure alarms."

Input Item 3) : The current wafer No. and lot ID are displayed on the screen.

The chamber name is displayed in the character string set from "Setting" → "ChamberName" from the menu after the sensor is connected.

Output Item 2) : Output data is fixed to specific pressure. If you select A or ppm as the setting of Y-axis spec, it cannot shift to auto measuring mode at the recipe setting dialog.

Output Item 4) : When a communication error, FIL error, RF error or disk storage error occurs, it outputs.

# PLC communication

- Output Item 5) : When automatic measurement mode is selected and trend mode measurement, it outputs value "1".
- Output Item 7) : When connected the sensor can be switched to [A] or [Pa] unit of Y axis of the recipe available.  
Output 1:[A] or 0:[Pa].  
\*Switching to [ppm] is not possible.


## 9.2 Set the communication

Set the IP address and COM port number of communication for the PLC.

1. Execute "/Mserv/exe/Mserver.exe" from the installation folder of the Residual Gas Analyzer.
2. Double-click "Unit0" in the dialog box.



3. Input "IP Address" and "Port Number" in the dialog box and press [OK] button.



4. After confirming that COMM STAT display has become Comm OK on #2 display, right-click on MSERVER on task bar and finish.
5. If COMM STAT display says Disconnect, check the IP address, sub net mask and status of the PLC start-up, then adjust the network's current connection with ping commands. Depending on the system, the IP Address of the PLC and its port No. could be different.

## 9.3 Save data

When automatic measurement mode is selected and trend mode measurement, data is saved at each date when start measurement and at each lot.

# PLC communication

Measurement end time: Continuous, Data saving: Operated according to the recipe setting per sampling.

Due to the system structure, if the substrate number and lot ID cannot be identified, measurement data for each lot cannot be saved.

The default folder saving data. (for sensor 1)

- 1) At each date : "(The installation folder of Residual Gas Analyzer)/S1/DateFile"
- 2) At each Lot : "(The installation folder of Residual Gas Analyzer)/S1/LotFile"

For other modes.

: "(The installation folder of Residual Gas Analyzer)/S1"

## 9.4 Setting partial pressure alarms

In the trend mode, the items to be set on the partial pressure alarm setting screen are as follows:

AlarmValue1 (upper limit), AlarmValue2 (upper limit),

ErrorValue1 (Upper limit), ErrorValue2 (upper limit)

The status of the input item 2) [DV status] of the PLC communication is referred to. An alarm is output when the status is DV-OPEN and an error is output when the status is DV-CLOSE. In the local mode, alarm and error are output irrespective of the DV status.

## 9.5 Auto degas

Degas can be done automatically.

Degas starts when it receives a start signal from Degas. The degas setting is fixed at the following values and cannot change:

[Degas setting]

DEGAS MODE: FAST

Maximum output: 100%

Time DEGAS: 1 hour

Screen in Degas remains in Trend mode. Screen operation is prohibited.

## 9.6 Auto sensitivity calibration

[Sensitivity calibration] can be done automatically.


Only [Calibration by SEM gain] mode is possible.

## 9.7 Connect to a sensor


When connecting to a sensor, the following screen will be displayed.

The measuring chamber name will be displayed next to a sensor number.

Select a sensor corresponding to the name of the chamber you would like to measure.



When using upright equipment, there are some cases where the following screen will be displayed. In this case, select the structure of the chamber, then you can select a sensor to connect.



## 10 CCLink-IE

### 10.1 Overview



**NOTICE:**

CCLink-IE communication function, AM function is an optional feature. Cannot be used in the standard function. Use it after confirming the operating conditions. One room in the PCI slot is required.

---

It can be used with the AM function. It communicates with the CCLink-IE if the automatic measurement mode of the AM function is selected. It will output the divided value and mass number from the CCLink-IE board. It is not possible to start-up from the input of the CCLink-IE board.

Use conditions 1:

- Vertical axis units [Pa].
- Automatic measurement mode.
- Trend mode.
- AM function is available.
- Normal station Residual Gas Analyzer side.
- Limited by software to address. Inquire at the time of use.
- For support boards, inquire at the time of use.

To fulfill all the above conditions.

Use conditions 2:

[Output Item]

-Bit-

- Residual Gas Analyzer Alarm
- Data enabled or disabled
- Partial pressure set point

-Word-

- Life time
- Mass number
- Partial pressure data


- Output item bit 1) : Output when a communication error, abnormal filaments or RF abnormalities such as a disk space error has occurred.
- Output item bit 2) : Outputs a "1" measurement in automatic measurement mode.
- Output item bit 3) : This signal will be output when it exceeds the partial pressure set point set.
- Output item word 1) : Life time will add 1 after writing the data. Next 1000 will return to 0.
- Output item word 2) : Prints the mass number.
- Output item word 3) : The output data is in fixed pressure. You cannot use the automatic measurement mode if you selected (ppm or A) other than pressure in the recipe.

## 10.2 Setting the communication

You can change channels No, network No and the area code from: "(The installation folder of Residual Gas Analyzer) \ CCLINK\_PARAM.INI".

The state after the change will be displayed as follows:

Ex) Channel No: 151, Network No: 1, Area code: 2



## 11 CCLink-IE2

### 11.1 Overview

"11. CCLink-IE function" starts and stops measurement with the AM option, but can also start and stop from the host. For the start condition, as with the PLC function, assign the DG or IG pressure, PV state to the link device.

You can output mass number, partial pressure value, etc. to the link device.

Use conditions:

- Vertical axis units [Pa].
- Automatic measurement mode.
- Trend mode.(Scan mode is also possible in option setting.)
- Normal station Residual Gas Analyzer side.
- Limited by software to address. Inquire at the time of the use.
- For support boards, inquire at the time of use.

Inputs and outputs:

[Input Item]

1. Hot cathode pressure, PV status

[Output Item]


1. Measurement Mass number
2. Partial pressure data, Total pressure data
3. Partial pressure set point
4. System error
5. Measurement status
6. Counter to check communication
7. Unit of Y axis

### 11.2 Setting the communication

You can change channels No, network No and the area code from: "(The installation folder of Residual Gas Analyzer) \ CCLINK\_PARAM.INI".

The state after the change will be displayed as follows:

Ex) Channel No: 151, Network No: 1, Area code: 2



# Sensor unit maintenance

## 12 Sensor unit maintenance

### 12.1 Overview

The Sensor Unit Maintenance function can execute Adjust FC (Faraday cup) offset function, adjust SEM offset function, initialize the table of the Mass No. Calibration function, Status Check function and command send function of each sensor.

### 12.2 Sensor unit maintenance screen

With the sensor connected, click the "Sensor Unit Maintenance" of the main menu to display the sensor unit maintenance screen.




Fig. 12.1 Select sensor unit maintenance




Fig. 12.2 Sensor unit maintenance screen

### 12.3 Adjust FC offset function

Click "Adjust FC offset" on the sensor unit maintenance screen to execute the Faraday cup (FC) offset function of the connected sensor.

# Sensor unit maintenance




Fig. 12.3 FC offset function adjust

## < Procedure >


1. Click "Adjust FC offset" on the sensor unit maintenance screen.
2. Displays a screen confirming that the sensor pressure is  $1e - 3$  Pa or less.
3. If the sensor pressure is  $1e - 3$  Pa or less, click "OK".

Click "Cancel" to cancel Adjust FC offset.




4. During Adjust FC offset, the "Now Adjust FC offset" screen is displayed.

Click "Cancel" to cancel Adjust FC offset.



5. When Adjust FC offset completes, the "FC offset adjustment is finished" screen will be displayed. Click "OK" and close the display.



## 12.4 Adjust SEM offset function

Click "Adjust SEM offset" on the sensor unit maintenance screen to execute the SEM offset function of the connected sensor.




Fig. 12.4 SEM offset function adjust

< procedure >

1. Click "Adjust SEM offset" on the sensor unit maintenance screen.
2. Displays a screen confirming that the sensor pressure is  $1e - 3$  Pa or less.
3. If the sensor pressure is  $1e - 3$  Pa or less, click "OK".

Click "Cancel" to cancel Adjust SEM offset.




4. During Adjust SEM offset, the "Now Adjust SEM offset" screen is displayed.

Click "Cancel" to cancel Adjust SEM offset.



5. When Adjust SEM offset completes, the "SEM offset adjustment is finished" screen will be displayed. Click "OK" and close the display.

# Sensor unit maintenance



## 12.5 Initialize table of Mass No. Calibration

Click "Initialize table of Mass No. Calibration" on the sensor unit maintenance screen to execute the Initialize table of Mass No. Calibration function of the connected sensor.






Fig. 12.5 Initialize table of Mass No. Calibration

< procedure >


1. Click "Initialize table of Mass No. Calibration" on the sensor unit maintenance screen.
2. The "Initialize Mass No. Calibration Execution Confirmation" screen will be displayed.
3. Click "OK" to execute Initialize table of Mass No. Calibration.

Click "Cancel" to cancel Initialize table of Mass No. Calibration.




4. During Initialize table of Mass No. Calibration, the "Now Initialize table of Mass No. Calibration " screen is displayed.

# Sensor unit maintenance



5. When Initialize table of Mass No. Calibration completes, the " Initialize table of Mass No. Calibration is Initialized" screen will be displayed. Click "OK" and close the display.



## 12.6 Status Check

Click " Status Check " on the sensor unit maintenance screen to execute the Status Check function of the connected sensor.




Fig. 12.6 Select status check

### < Procedure >

1. Click "Status Check " on the Sensor Unit Maintenance screen.

"Status Check" screen is displayed.

# Sensor unit maintenance




Fig. 12.7 Status check screen

- |   |  |
|---|--|
| AD00: Total pressure value x1,000 times | AD08: +90V monitoring value                |
| AD01: Total pressure value x100 times   | AD09: +200V/-100V Voltage monitoring value |
| AD02: Total pressure value x10 times    | AD10: Analog1 input value                  |
| AD03: Total pressure value x1 times     | AD11: Analog2 input value                  |
| AD04: Emission current monitoring value | AD12: Partial pressure x1,000 times        |
| AD05: SEM Voltage monitoring value      | AD13: Partial pressure x100 times          |
| AD06: RF current monitoring value       | AD14: Partial pressure x10 times           |
| AD07: Temperature monitoring value      | AD15: Partial pressure x1 times            |

2. Click "OK" and close the display.

## 12.7 Command send

When the operator enters a command in the command input area and clicks "Send", the command can be sent to the connected sensor. Command send/receive records are displayed in the dedicated area.




Fig. 12.8 Command send

1. Command input area
2. Send button
3. Command send/receive recording display area

# Optional IP Address setting function

## 13 Optional IP Address setting function

### 13.1 Overview

This function can set the optional IP address of each sensor.

### 13.2 Optional IP Address setting screen

In this screen, with sensor connection, press the "Optional IP address setting" from the main

menu to display the optional IP address setting screen.




Fig. 13.1 Command send

When displaying an optional IP address setting screen, the IP address to be displayed first is the optional IP address set in the Residual Gas Analyzer. Setting the optional IP address and pressing the OK button rewrites Residual Gas Analyzer's optional IP address.



# Sales and Service

## Germany

### Leybold GmbH

Bonner Strasse 498  
D-50968 Cologne  
T: +49-(0)221-347 1234  
F: +49-(0)221-347 31234  
sales@leybold.com  
www.leybold.com

### Leybold GmbH

**Sales Area North**  
Branch Office Berlin  
Industriestrasse 10b  
D-12099 Berlin  
T: +49-(0)30-435 609 0  
F: +49-(0)30-435 609 10  
sales.bn@leybold.com

### Leybold GmbH

**Sales Office South**  
Branch Office Munich  
Karl-Hammerschmidt-Strasse 34  
D-85609 Aschheim-Dornach  
T: +49-(0)89-357 33 9-10  
F: +49-(0)89-357 33 9-33  
sales.mn@leybold.com  
service.mn@leybold.com

### Leybold Dresden GmbH

**Service Competence Center**  
Zur Wetterwarte 50, Haus 304  
D-01109 Dresden  
Service:  
T: +49-(0)351-88 55 00  
F: +49-(0)351-88 55 041  
info.dr@leybold.com

## Europe

### Belgium

### Leybold Nederland B.V.

**Belgisch bijkantoor**  
Leuvensesteenweg 542-9A  
B-1930 Zaventem  
Sales:  
T: +32-2-711 00 83  
F: +32-2-720 83 38  
sales.zv@leybold.com  
Service:  
T: +32-2-711 00 82  
F: +32-2-720 83 38  
service.zv@leybold.com

### France

### Leybold France S.A.S.

Parc du Technopolis, Bâtiment Beta  
3, Avenue du Canada  
F-91940 Les Ulis cedex  
Sales and Service:  
T: +33-1-69 82 48 00  
F: +33-1-69 07 57 38  
info.ctb@leybold.com  
sales.ctb@leybold.com

### Leybold France S.A.S.

Valence Factory  
640, Rue A. Bergès  
B.P. 107  
F-26501 Bourg-lès-Valence Cedex  
T: +33-4-75 82 33 00  
F: +33-4-75 82 92 69  
marketing.vc@leybold.com

## Great Britain

### Leybold UK LTD.

Unit 9  
Silverglade Business Park  
Leatherhead Road  
Chessington  
Surrey (London)  
KT9 2QL  
Sales:  
T: +44-13-7273 7300  
F: +44-13-7273 7301  
sales.ln@leybold.com  
Service:  
T: +44-13-7273 7320  
F: +44-13-7273 7303  
service.ln@leybold.com

## Italy

### Leybold Italia S.r.l.

Via Filippo Brunelleschi 2  
I-20093 Cologno Monzese  
Sales:  
T: +39-02-27 22 31  
F: +39-02-27 20 96 41  
sales.mi@leybold.com  
Service:  
T: +39-02-27 22 31  
F: +39-02-27 22 32 17  
service.mi@leybold.com

## Netherlands

### Leybold Nederland B.V.

Floridadreef 102  
NL-3565 AM Utrecht  
Sales and Service:  
T: +31-(30) 242 63 30  
F: +31-(30) 242 63 31  
sales.ut@leybold.com  
service.ut@leybold.com

## Switzerland

### Leybold Schweiz AG

Hinterbergstrasse 56  
CH-6312 Steinhausen  
Warehouse and shipping address:  
Riedthofstrasse 214  
CH-8105 Regensdorf  
Sales:  
T: +41-44-308 40 50  
F: +41-44-302 43 73  
sales.zh@leybold.com  
Service:  
T: +41-44-308 40 62  
F: +41-44-308 40 60  
service.zh@leybold.com

## Spain

### Leybold Hispánica, S.A.

C/. Huelva, 7  
E-08940 Cornellá de Llobregat  
(Barcelona)  
Sales:  
T: +34-93-666 43 11  
F: +34-93-666 43 70  
sales.ba@leybold.com  
Service:  
T: +34-93-666 46 11  
F: +34-93-685 43 70  
service.ba@leybold.com

## America

## USA

### Leybold USA Inc.

5700 Mellon Road  
USA-Export, PA 15632  
T: +1-724-327-5700  
F: +1-724-325-3577  
info.ex@leybold.com  
Sales:  
T: +1-724-327-5700  
F: +1-724-333-1217  
Service:  
T: +1-724-327-5700  
F: +1-724-325-3577

## Brazil

### Leybold do Brasil

Rod. Vice-Prefeito Hermenegildo Tonolli,  
nº. 4413 - 6B  
Distrito Industrial  
Jundiá - SP  
CEP 13.213-086  
Sales and Service:  
T: +55 11 3395 3180  
F: +55 11 99467 5934  
sales.ju@leybold.com  
service.ju@leybold.com

## Asia

### P. R. China

### Leybold (Tianjin)

**International Trade Co. Ltd.**  
Beichen Economic  
Development Area (BEDA),  
No. 8 Western Shuangchen Road  
Tianjin 300400  
China  
Sales and Service:  
T: +86-400 038 8989  
F: +86-800 818 0033  
F: +86-22-2697 4061  
F: +86-22-2697 2017  
sales.tj@leybold.com  
service.tj@leybold.com

## India

### Leybold India Pvt Ltd.

T-97/2, MIDC Bhosari  
Pune-411 026  
Indien  
Sales and Service:  
T: +91-80-2783 9925  
F: +91-80-2783 9926  
sales.bg@leybold.com  
service.bg@leybold.com

## Japan

### Leybold Japan Co., Ltd.

Headquarters  
Shin-Yokohama A.K.Bldg., 4th floor  
3-23-3, Shin-Yokohama  
Kohoku-ku, Yokohama-shi  
Kanagawa-ken 222-0033  
Japan  
Sales:  
T: +81-45-471-3330  
F: +81-45-471-3323  
sales.yh@leybold.com

### Leybold Japan Co., Ltd.

Tsukuba Technical Service Center  
1959, Kami-yokoba  
Tsukuba-shi, Ibaraki-shi 305-0854  
Japan  
Service:  
T: +81-29 839 5480  
F: +81-29 839 5485  
service.iik@leybold.com

## Malaysia

### Leybold Malaysia

### Leybold Singapore Pte Ltd.

No. 1 Jalan Hi-Tech 2/6  
Kulim Hi-Tech Park  
Kulim, Kedah Darul  
Aman 09000  
Malaysia  
Sales and Service:  
T: +604 4020 222  
F: +604 4020 221  
sales.ku@leybold.com  
service.ku@leybold.com

## South Korea

### Leybold Korea Ltd.

3F. Jellzone 2 Tower  
Jeongja-dong 159-4  
Bundang-gu Sungnam-si  
Gyeonggi-do  
Bundang 463-384, Korea  
Sales:  
T: +82-31 785 1367  
F: +82-31 785 1359  
sales.bd@leybold.com  
Service:  
623-7, Upsilon-Dong  
Cheonan-Si  
Chungcheongnam-Do  
Korea 330-290  
T: +82-41 589 3035  
F: +82-41 588 0166  
service.cn@leybold.com

## Singapore

### Leybold Singapore Pte Ltd.

42 Loyang Drive  
Loyang Industrial Estate  
Singapore 508962  
Singapore  
Sales and Service:  
T: +65-6303 7030  
F: +65-6773 0039  
sales.sg@leybold.com  
service.sg@leybold.com

## Taiwan

### Leybold Taiwan Ltd.

10F., No. 32, Chenggong 12th St.,  
Zhubei City, Hsinchu County 302  
Taiwan, R.O.C.  
Sales and Service:  
T: +886-3-500 1688  
F: +886-3-550 6523  
sales.hc@leybold.com  
service.hc@leybold.com

## Headquarter

### Leybold GmbH

Bonner Strasse 498  
D-50968 Cologne  
T: +49-(0)221-347-0  
F: +49-(0)221-347-1250  
info@leybold.com



www.leybold.com