

Turbo.Drive TD20 classic

Frequency Converter for Turbomolecular Pumps

Operating Instructions GA05228_002_C0

Part Nos.

800075V0001 to
800075V0008



Contents

		Page
	Important Safety Information	3
1	Description	4
1.1	Design and function	4
1.2	Supplied equipment	4
1.3	Technical data	6
1.4	Ordering information	7
1.5	Accessories	7
2	Installation	8
2.1	Placement	8
2.2	Conforming utilisation	8
2.3	Providing the connections	9
2.4	Replacing the NT 20	10
2.5	Replacing the NT 151/361 or NT 361	13
3	Operation	14
3.1	Start-up	14
3.2	Interfaces	15
3.2.1	9-way PLC interface	16
3.2.2	RS 232 interface	17
3.2.3	Profibus interface	18
3.2.4	RS 485 interface	18
3.2.5	25-way PLC interface	20
3.2.6	DeviceNet interface	22
3.2.7	Ethernet/IP interface	22
3.2.8	Parameter list	23
3.2.9	Specific parameter data for the pumps	27
3.2.10	Error messages	28
3.3	Start-up of the TURBOVAC	29
3.4	Operation	29
3.4.1	Status table at default settings	29
3.5	Shut-down of the TURBOVAC	30
3.6	Shut-down of the Turbo.Drive TD20 <small>classic</small>	30
4	Maintenance	30
5	Troubleshooting	31
	EC Conformance Declaration	33
	Certificates	34

Safety Information

Important Safety Information

Indicates procedures that must be strictly observed to prevent hazards to persons.

Indicates procedures that must be strictly observed to prevent damage to, or destruction of the product.

The Leybold **Turbo.Drive TD20 *classic*** frequency converter has been designed for safe and efficient operation when used properly and in accordance with these Operating Instructions. It is the responsibility of the user to carefully read and strictly observe all safety precautions described in this section and throughout the Operating Instructions. The Turbo.Drive **must only be operated in the proper condition and under the conditions described in the Operating Instructions**. It must be operated and maintained by trained personnel only. Consult local, state, and national agencies regarding specific requirements and regulations. Address any further safety, operation and/or maintenance questions to our nearest office.

Only qualified personnel or the Leybold Service Department may carry out work on the frequency converter.

Potentially fatal voltages are present inside the frequency converter. Open the frequency converter only after it has been isolated from the mains power supply.

We reserve the right to alter the design or any data given in these Operating Instructions. The illustrations are not binding.

Warning

Caution



Warning



Description

1 Description

1.1 Design and function

The electronic frequency converter Turbo.Drive TD20 ^{classic} is used to drive the following turbo molecular pumps:

- TURBOVAC 151, 151 C, 361, 361 C
- TURBOVAC 600, 600 C,
- TURBOVAC 1000, 1000 C, 1100 C

These pumps each comprise a three-phase asynchronous motor with the appropriate rating to drive the rotor.

The Turbo.Drive TD20 ^{classic} converts the single-phase mains voltage into a three-phase AC voltage with regulated frequency and amplitude.

Coding


Each installed TURBOVAC has been individually coded. The acceleration sequence, the regulation during operation, and the output speed will vary depending on the installed pump model.

The Turbo.Drive TD20 ^{classic} has a 9-way PLC interface as standard and additional interfaces as option. It can be connected directly to mains voltage.

The Turbo.Drive TD20 ^{classic} can be connected directly to mains voltage.

1.2 Supplied equipment

Turbo.Drive TD20 ^{classic} table-top electronic frequency converter with housing, Operating Instructions.



green LED STATUS	
off:	Pump at standstill or decelerating
flashes 250 ms on, 750 ms off	Start delay time
flashes slowly 1/s:	Start command is present (for about 10 s after start)
flashes fast 3/s:	Running up or running down
on:	Normal operation
<hr/>	
yellow LED POWER	
off:	No supply voltage
flashes:	Supply voltage too low
on:	Supply voltage is present
<hr/>	
red LED ERROR	
off:	No error, no warning
flashes:	Warning is present, pump can be operated possibly with some restrictions
on:	Fault is present, pump stopped and can not be operated
<hr/>	
LED chain LOAD	
after POST	indicates the recognized pump
LED STATUS flashes (Run-up)	indicates the TURBOVAC's speed
LED STATUS on (Normal operation)	indicates the motor current
LED ERROR on (Error)	indicates the error code
<hr/>	
SERVICE interface	RS 232 interface
<hr/>	
Key START	Starting the TURBOVAC's run-up
<hr/>	
Key STOP	Switching the TURBOVAC off Resetting a failure report
<hr/>	

Fig. 1.1 Front panel of the Turbo.Drive TD20 classic

Description




Fig. 1.2 Dimensional drawing for the Turbo.Drive TD20 ^{classic}, dimensions in mm

1.3 Technical data

Mains connection	100 to 240 V AC -15%/+10%, 50/60 Hz
Power consumption tolerance including options	< 500 VA
Power consumption of the TURBOVAC	< 400 VA
Power output (motor)	
Nominal voltage	47 V
Motor current limitation	
Acceleration (max. 10 min.)	5 A
Continuous operation	3.5 A
Frequency	0 to 835 Hz

TURBOVAC speed ratings





TURBOVAC 151	49,980 min ⁻¹
TURBOVAC 361	45,000 min ⁻¹
TURBOVAC 600	36,000 min ⁻¹
TURBOVAC 1000	36,000 min ⁻¹
TURBOVAC 1100	30,000 min ⁻¹

Ambient temperature	0-45 °C
Storage temperature	-25 °C...+70 °C
Relative air humidity	5 to 85 % (non-condensing)
Type of protection to EN 6059	IP 20
Electrical safety to EN 61010-1	
Interference radiation to 61326-1	Class A
EMC to IEC 801-2	Severity 2
Dimensions	1/2 19", 3HU
Weight	4 kg

1.4 Ordering information

	Part No.
Frequency converter Turbo.Drive TD20 ^{classic}	
with 9-way PLC interface	800075V0001
with additional RS 232 interface	800075V0002
with additional Profibus interface	800075V0003
with additional RS 485 interface	800075V0004
with additional 25-way PLC interface	800075V0005
with additional DeviceNet interface	800075V0006
with additional Ethernet/IP interface	800075V0007
with 9-way PLC interface and adapter for pump connection with DIN plug; see Fig. 2.6 (in case of replacement of NT 151/361 or NT 361)	800075V0008

1.5 Accessories

Connection line to the TURBOVAC		
3 m long	857 65	
5 m long	857 66	
10 m long	857 67	
20 m long	857 68	
Power line cord		
3 m long, Euro plug	800102V0002	
3 m long, US plug 6-15 P	800102V1002	
Mounting frame 19", 3HU	161 00	
Adapter cable, 0.2 m long, 25-way PLC interface – 2x Phoenix connector of the NT 20	800152V0020	
Adapter cable, DRIVE connector of the Turbo.Drive TD20 ^{classic} – TURBOVAC connection cable of the NT 151/361 or NT 361	800 000 006	

Accessories for serial interfaces

PC software „Turbo.Drive Server“ for Windows 95 and higher, CD-ROM	
■ Display, change, save and compare parameter lists	
■ Integration of customer's software	
■ Record parameter data	800110V0102
(Software supports only RS 232, RS 485 and Profibus)	
The software can also be downloaded from www.leybold.com in the menu Documentation → Download Software	

Installation

2 Installation

Warning



Only qualified personnel or the Leybold Service Department may carry out work on the frequency converter.

Potentially fatal voltages are present inside the frequency converter. Open the frequency converter only after it has been isolated from the mains power supply.

2.1 Placement

Place the Turbo.Drive TD20 ^{classic} on a flat, smooth surface.

For installation in a rack use the mounting frame 19", 3 HU.

Warning



The heat dissipation of the Turbo.Drive TD20 ^{classic} must not be obstructed. Insure a sufficient ventilation - the ambient temperature during operation must not exceed 45 °C (113 °F).

Warning



If the Turbo.Drive TD20 ^{classic} is built into a rack the mains plug is not within easy reach. Therefore install a separation between the Turbo.Drive TD20 ^{classic} and the mains when you build it into a rack.

Warning



Do not operate the Turbo.Drive TD20 ^{classic} with the standard mains lead in chemically aggressive surroundings. If you operate the Turbo.Drive TD20 ^{classic} in chemically aggressive surroundings replace the mains lead by a resistant one.

2.2 Conforming utilisation

The electronic frequency converter Turbo.Drive TD20 ^{classic} is used to drive the following turbo molecular pumps:

TURBOVAC 151, 151 C, 361, 361 C,
TURBOVAC 600, 600 C,
TURBOVAC 1000, 1000 C, 1100 C.

Other turbomolecular pumps **must not** be connected.




Fig. 2.1 Turbo.Drive TD20 classic, rear panel

2.3 Providing the connections

Insert and fasten the connection line to the motor of the TURBOVAC.

Connect the interface, see Section 3.2.

Connect the instrument using the ground bolt to the protective ground system.

Warning



Connect the power line cord.

Installation




Fig. 2.2 TURBOTRONIK NT 20, rear panel

2.4 Replacing the NT 20

The Turbo.Drive TD20 ^{classic} is capable of replacing the NT 20.

The connection for the **power line cord** is identical, an adjustment to the mains voltage is no longer required.

The connection for the **TURBOVAC** is identical. You can use the old connection cable.

The connections FOREPUMP, VALVE, HEATER and FAN are no longer present on the Turbo.Drive TD20 ^{classic}. Connect corresponding equipment directly to the system controller.

The DIP switches (INTERFACE) need no longer to be set up, the Turbo.Drive TD20 ^{classic} is capable of detecting the pumps automatically, see Section 3.1 Start up.

The PLC interface **REMOTE** has been replaced

- for some functions by the standard 9-way PLC interface REMOTE X1.
- for all functions by the optional 25-way PLC interface. When wanting to continue to use the old cable with the Phoenix contact strips, we are offering for this purpose an adapter, see Section 1.5 and Fig. 2.3.

The pin assignments of both interfaces are detailed in Section 3.2.1 and 3.2.5.




Fig. 2.3 NT 20 adapter

Installation




Fig. 2.4 Connections for the Turbo.Drive TD20 classic, schematic representation




Fig. 2.5 Connections for the Turbo.Drive TD20 classic, with adapter cable, schematic representation




Fig. 2.6 Turbo.Drive TD20 ^{classic}, version for version for pump connection with DIN plug

2.5 Replacing the NT 151/361 or NT 361

The Turbo.Drive TD20 ^{classic} is capable of replacing the NT 151/361 and the NT 361.

The connection for the **power line cord** is identical, an adjustment to the mains voltage is no longer required. You can use the old power line cord.

The connection for the **TURBOVAC** is different. We recommend using a new connection cable. If you want to use the old connection cable you need the adapter cable 800 000 006.

Alternatively you may use the Turbo.Drive TD20 ^{classic} version for pump connection with DIN plug (compatible with the NT 361 pump connector).




Fig. 3.1 Pump identification at the LOAD LEDs

3 Operation

Controlling the instrument through the keys START and STOP and the 9-way PLC interface has equal priority. When controlling the instrument through optional boards (Profibus or RS 485, for example), the keys and the 9-way PLC interface are disabled.

3.1 Start-up

Switch the frequency converter on via the switch on the rear. After doing so, the start-up self test begins.

The parameters stored in the EEPROM are read and the connected pump is detected. After approximately 15 seconds the frequency converter is ready to start.

If after this process the red LED ERROR is on, then the connected pump was not detected. If, moreover, two of the LEDs LOAD flash alternately, then a different pump was detected (long flashing intervals: detected pump; short flashing intervals: stored pump; for pump assignments refer to Fig. 3.1).

In both cases a special acknowledgement will be necessary: while keeping the STOP key depressed, press the START key and release it again, thereafter release the STOP key.

Caution

Through this special acknowledgement process the user acknowledges the change of pump and the correctness of the pump which has been detected.

Note

Upon delivery, the Turbo.Drive TD20 classic has been preset to the TURBOVAC 1100 so the special acknowledgement process will have to be run when commissioning any other pump for the first time.

3.2 Interfaces

The Turbo.Drive TD20 ^{classic} is equipped as standard with a 9-way PLC interface and optionally with one more:

- RS 232
- Profibus
- RS 485
- 25-way PLC interface
- DeviceNet
- Ethernet

The Turbo.Drive TD20 ^{classic} is configured through the parameters according to the parameter list. Pxxx denotes parameter value xxx.

The PC software „TURBO.DRIVE Server“ allows convenient access by the user to the parameters of the frequency converter.

For further information on the interfaces refer to the Operating Instructions which are included with the respective device.

Operation




Fig. 3.2 9-way PLC interface X1

3.2.1 9-way PLC interface

Controlling the instrument through the keys START and STOP and the 9-way PLC interface has equal priority.

The control lines for the interface respond to the rising or falling flank of a +24 V DC signal.

When the pump is started through X1 and then the STOP key is pressed, the pump will be switched off, but 24 V is still present at X1. For starting the pump through X1 give a stop signal at first and then a start signal.

The same applies vice versa: When a stop signal is present at X1 and the pump is started with the START key, give a start signal at first and then a stop signal for stopping the pump.

When **switching on** the Turbo.Drive TD20 classic the **status** at X1 will be utilized.

The other (optional) interfaces behave differently. When controlling the instrument through them, the keys are disabled (except from the start-up).

3.2.2 RS 232 interface

Standards	DIN 66020
Protocol	acc. to VDI/VDE 3689
Transmission rate	19200 baud
Response delay	default setting 10 ms (parameter 180)
Address range	non-addressable
Max. cable length	15 m
Interface connector	9 way Sub-D type, socket on the instrument (female) thread UNC4-40

Note: If on the controlling side an RS 232 interface in accordance with the PC standard with a 9-pin Sub-D male connector is present, then a straight through cable as shown in Fig. 3.4 may be used.

For further information please refer to the Operating Instructions 17200048.




Fig. 3.3 Pin assignment for the socket at the frequency converter (female)




Fig. 3.4 Providing a RS 232 connection

3.2.3 Profibus interface

Please refer to the Operating Instructions 17200049.

3.2.4 RS 485 interface

Standards	ISO/IEC 8482, EIA 485
Protocol	acc. to VDI/VDE 3689
Transmission rate	19200 baud fixed
Response delay	default setting 10 ms (parameter 180)
Address range	0 ... 15
Max. cable length	50 m (with bus termination)
Type of cable	2 wire twisted pair (twisted pair cable)
Differential voltage levels (see also "Standards")	logic „0“: transmitter: 1.5 ... 5 V receiver: > 0.3 V logic „1“: transmitter: - 1,5 ... - 5 V receiver: ≤ - 0,3 V
Interface connector	9 way Sub-D type, socket on the instrument (male) thread UNC4-40

Note: After having changed the bus address through the rotary switch, the frequency converter must be switched off (yellow power LED off) and then on again so as to enable the new address setting.

For further information please refer to the Operating Instructions 17200048.




Fig. 3.5 Pin assignment for the socket at the frequency converter for RS 485 interface (male)




Fig. 3.6 Connection of the RS 485 bus

Operation

3.2.5 25-way PLC interface

Observe the EMC requirements when connecting the control cables.






Pin assignment for the 25-way PLC interface

Pin	Assignment	Function	Ref. potential
1	Remote[H] (input)	Activates by a H level the inputs Start[H], Stop[H], option 1 to 3 [H]	Control GND
2	Start[H] (input)	PLC H pulse starts the pump, provided Remote[H] = H (duration > 99ms)	Control GND
3	Stop[L] (input)	PLC L pulse stops the pump, provided Remote[H] = L (duration > 99ms)	Control GND
4	Control GND	Reference ground for floating PLC control inputs	
5	Supply GND	Reference ground of for auxiliary power supply pin 6	
6	PLC-H signal and power supply	Auxiliary power supply for externally connected equipment. The output voltage corresponds mainly to the input voltage delivered by the host, output voltage 24 V DC Current output 80 mA Current limiting without foldback characteristic, no shutdown in case of excessively high currents, however shutdown in case of overtemperatures.	Supply GND
7	reserved		
8	Error (relay)	Collective error message, active in case of a fault (n.o.)	Pin 8
9	Error (relay)	Collective error message, com.	
10	Normal (relay)	Final rotational frequency has almost been attained (n.o.). For function and threshold the parameters 25, 27 and 29 apply. See parameter 237	Pin 11
11	Normal (relay)	Final rotational speed has almost been attained, com.	
12	Option relay 2	Normally open contact (n.o.) enabled with valve and forevacuum; see parameter 240	Pin 13
13	Option relay 2	com.	
14	reserved		
15	reserved		
16	Option relay 1	Assigned to run-up, com.; see parameter 239	
17	reserved		
18	Option relay 3	Normally open contact (n.o.).assigned with function "motor current"; see parameter 318	Pin 19
19	Option relay 3	com.	
20	Option relay 3	n.c.	Pin 19
21	Error (relay)	Collective error message (active in case of a fault), (n.c.)	Pin 8
22	reserved		
23	Option relay 1	Is enabled in case of a speed increase, normally open (n.o.); see parameter 239	Pin 16
24	reserved		
Casing	Frame GND	Connected to frame ground (PE)	

PLC = Programmable logic controller [H] = PLC high level > 11 V [L] = PLC low level < 8 V
Input resistance 5...6kΩ External voltage resistance ± 40VDC

The reserved pins must not be used.

Relays

Pin	Relay	Function
10	Normal n.o.	 <p>Contact closed: Rotor speed has attained 80% of its nominal speed. (= normal operation). The relay picks up as soon as the normal operation threshold is attained.</p>
11	Normal com.	
8	Fault n.o.	 <p>Outputs an error message. When the error relay switches, the pump is shut down. The relay is energised in the case of normal operation.</p> <p>Possible error causes:</p> <ul style="list-style-type: none"> ■ The pump was overloaded for a longer period of time. ■ The minimum rotational speed was not attained within a limited period of time. ■ The speed has dropped below the lower limit. ■ The rotor or bearing temperature is above the fault limit. ■ Internal electrical error.
9	Fault com.	
21	Fault n.c.	
Optional relay 1		 <p>Switches when the pump is being driven, the pump is running up.</p>
23	Run-up n.o.	
16	Run-up com.	
Optional relay 2		 <p>Switches when: start command is present, no error and mains power on. Can be used to control a valve or the backing pump.</p>
12	Valve and forevacuum n.o.	
13	Valve and forevacuum com.	
Optional relay 3		 <p>Supplies a start signal for the connected fan, if Parameter 318 has been set to 3. Upon delivery: The relay picks up as soon as normal operation is attained (motor current \leq normal current threshold).</p>
18	Fan n.o.	
19	Fan com.	
20	Fan n.c.	

Contact rating: 2A / 50V DC max. (resistive load)

Operation




Fig. 3.7 Example for external connections compatible with the NT 20 (principle)

3.2.6 DeviceNet interface

See additional Operating Instructions 17200055.

3.2.7 Ethernet/IP interface

See additional Operating Instructions 17200056.

3.2.8 Parameter list

* specific values for each pump; see table of pumps, Section 3.2.9; r = readable, w = writable

No.	Designation	min.	max.	Default	Unit	r/w	Format	Description
1	Converter type	100	160	160	-	r	u16	160 = Turbo.Drive TD20 <i>classic</i>
2	Software version x.yy.zz	0	65535	9059		r	u16	
3	Actual frequency	0	1000	0	Hz	r	u16	x.yy: Version, zz: Correction index
4	DC supply voltage	0	1000	0	0.1 V	r	u16	Rotary frequency of the rotating stator field
5	Actual current	0	100	0	0.1 A	r	u16	Constantly measured RMS value of the motor current.
8	Program EEPROM	-2147483648 2147483647		0		w	s32	A write command with any number value will initiate carrying over of the data.
11	Actual converter temperature	0	150	0	°C	r	u16	Constantly measured converter temperature.
17	Nominal motor current	0	100	70	0.1 A	r	u16	Maximum motor current
18	Max. frequency	0	1000	*	Hz	r	u16	Upper frequency limit.
19	Minimum setpoint frequency for the pump	P20	P18	500	Hz	r	u16	Lowest permissible frequency
20	Critical frequency	0	P18	*	Hz	r	u16	When the pump is accelerating this frequency must be reached within the maximum passing time (P183). After the end of acceleration: Switch-off threshold because of overload.
21	Max. current factor	0	100	73	%	r	u16	After attaining normal operation, the maximum motor current is limited to P17*P21.
23	Pump type	0	99	*		r	u16	*
24	Setpoint frequency	P19	P18	*	Hz	r	u16	Nominal frequency of the rotating stator field.
25	Frequency dependent normal operation threshold	70	85	80	%	r/w	u16	Defines from which frequency onwards there is normal operation for the pump.
27	Relay definition normal current	0	P17	20	0.1 A	r/w	u16	If P29 = 1 or 4: Defines from which motor current onwards there is the normal operation.

Operation

No.	Designation	min.	max.	Default	Unit	r/w	Format	Description
29	Selection of the relay functions at X1	0	5	0		R/W	u16	The normal operation and error relays can be set to special functions if required.
	P29 = 0 means:	the normal operation relay is active when the normal operation frequency is exceeded ($P3 \geq P24 * P25$) the error relay is active in case of an error {TDS/L compatible}						
	P29 = 1 means:	the normal operation relay is active when the current falls below the normal operation threshold ($P5 \leq P27$) the error relay is active in case of an error {TDS/L compatible}						
	P29 = 2 means:	the normal operation relay controls e.g. a venting valve, activated via the field bus interface (Bit 12 in the control word of the data transfer protocol) the error relay controls e.g. a purge gas valve, activated via the field bus interface (Bit 11 in the control word of the data transfer protocol) (makes only sense at interface operation)						
	P29 = 3 means:	the normal operation relay is active when the normal operation frequency is exceeded ($P3 \geq P24 * P25$) the error relay is active when no error exists {T1600 compatible}						
	P29 = 4 means:	the normal operation relay is active when the current drops below the normal operation threshold ($P5 \leq P27$) the error relay is active when no error exists						
	P29 = 5 means:	the normal operation relay is active in the case of Start and de-energised in the case of Stop, an error or a mains power failure and when the frequency drops below the frequency threshold defined through parameter 247 (Vent function) the error relay is active in case of an error						
32	Maximum run up time	P183	2000	*	s	r	u16	Max. permissible time during which the pump must attain the normal operation threshold ($P24 * P25$) with the start signal present.
36	Start delay time	0	255	0	0.1 min	r/w	u16	Delayed starting of the pump in order to allow time for the backing pump.
38	Start counter	0	65535	0		r	u16	Counts the total number of pump run-ups.
40	Error counter total	0	65535	0		r	u16	Counts the total number of error messages output.
41	Error counter overload	0	65535	0		r	u16	Counts of the total number of load limit error messages.
42	Error counter motor							Counts of the total number of pump temperature error messages.
43	Error counter mains supply	0	65535	0		r	u16	Counts the total number of mains power failures.
90	Error mode	0	2	2		r/w	u16	Selection of the error code table saved in P171: 2 = Default setting TD20 ^{classic} 1 = Compatible with T1600 0 = Compatible with MagDrive
127	Actual temperature pump housing	0	140	0	°C	r	u16	Measured pump housing temperature.
128	Warning temperature pump housing	0	P132	*	°C	r	u16	When the temperature warning threshold is exceeded, the warning message is output.

No.	Designation	min.	max.	Default	Unit	r/w	Format	Description
132	Limit temperature pump housing	0	140	*	°C	r	u16	Maximum permissible pump housing temperature, P125>P132 will shut the pump down.
171	Error code memory for the 40 most recent events	0	255	0		r	u16	Sequential permanent memory; the individual error codes are accessed via parameter 171 with additional index no. in the parameter order identifier of the interface protocol. The last error code which has occurred is saved at the memory location with the index 0, the oldest is at index 39. See Section 3.2.10 for the error codes.
174	Stator frequency at the time of error	0	P18	0	Hz	r	u16	Analogously as for P171 (error code memory)
176	Error operating hours memory for the 40 most recent error events	0	2147483647	0	0.01 h	r	u32	Analogously as for P171 (error code memory)
179	Response when cancelling the control rights or in the case of a communication interruption of the bus adapter	0	65535	0		r/w	u16	

Behaviour in case bit 10 in the control word of the bus adapter is cancelled or when interrupting the communication between converter and bus adapter (see also P182). Here it is assumed that the respective bus adapters perform a cyclic communication on the USS side, so that the respective converter electronics is capable of detecting a communication interruption

The bits in parameter 179 represent an equivalent to the control word in the USS protocol.

The actions linked to these bits are run provided bit 10 in the control word (USS protocol for bus adapter) is cancelled or if there are interruptions in the communication between converter and bus adapter.

Here bit 10 is of special significance:

Bit 10 = 0 The control rights are returned to the next lower priority level. All other bits are not relevant.

Bit 10 = 1 The control rights remain unchanged. The actions linked to the other bits are run.

180	Response delay time	2	19	10	ms	r/w	u16	Pause time between received string and the subsequent reply string (minimum interval)
181	Bus adapter baud rate	48	576	192	100/s	R/W	u16	Baud rate for RS 232/RS 485 options board, respectively internal baud rate for other bus adapter values: 48 = 4800 baud 96 = 9600 baud 192 = 19200 baud (standard) 288 = 28800 baud 576 = 57600 baud
182	Delay when cancelling the control rights of the bus adapter and time-out in the case of a communication interruption	0	65535	10	0.1 s	r/w	u16	

Defines the time characteristic when cancelling bit 10 in the control word of the USS protocol or when an interruption in the communication between bus adapter and converter and electronics is detected. Handling when cancelling bit 10 or when there is an interruption on the communication side of the USS bus adapter, is the same.

Value 0.0: Indefinite time delay. In this way a change of the control right is inhibited.

Values 0.1 ..6553.5: A change in the control right corresponding to the setting of parameter 179 is only effected after the time span defined through parameter 182 has elapsed.

Operation

No.	Designation	min.	max.	Default	Unit	r/w	Format	Description
183	Max. passing time	0	P32	500	s	r	u16	Maximum permissible time during which the pump with the start signal present must have passed the critical speed range between 60 Hz and P20.
184	Converter operation hours	0 2147483647		0	0.01 h	r	u32	Sums the operating hours of the converter during active pump operation.
199	Converter factory date	0	20991231	0		r	u32	Converter date of manufacture (YYYYMMDD).
227	Warning bits 1	0	65535	0		r	u16	Active warning, bit-wise representation: Bit 3 = Pump temperature warning (P127 > P128) Bit 11 = Overload warning (P3 < P25*P24 after normal operation has been attained, not evaluated during generator operation) Bit 14 = Power supply voltage warning (P4 > Umax or P4 < Umin or mains power failure)
237	Function normal operation relay on 25-way PLC interface	0	3	2		R/W	u16	0 = Off 1 = On 2 = Normal operation 3 = Heating (active at normal operation and High signal at digital input 1)
239	Function optional relay 1	0	2	2		R/W	u16	0 = Off 1 = On 2 = Acceleration (corresponds to bit 4 in the status word)
240	Function optional relay 2	0	5	4		R/W	u16	0 = Off 1 = On 2 = Pump is turning (corresponds to bit 11 in the status word) 3 = Converter is active (corresponds to bit 2 in the status word) 4 = Valve and forevacuum (active for driven pump) 5 = Power failure venting (active at frequency above P247)
243	Time delay SEMI F47	0	6000	500	0.01 s	r/w	u16	Adjustable time which in the case of an AC voltage breakdown is bridged without an error message. For the entire duration, the converter will indicate a normal operation. Auxiliary parameter for fulfilling SEMI F47 requirements.
247	Power failure "vent on" frequency	P248	P18	300	Hz	R/W	u16	Frequency at which the venting valve shall be switched on in case of a mains power failure. Power failure venting can be enabled through P240.
248	Power failure "vent off" frequency	0	P247	5	Hz	R/W	u16	Frequency at which the venting valve shall be switched off in case of a mains power failure. Power failure venting can be enabled through P240.
254	RS 485 address	0	31	0		R/W	u16	Currently valid address at the bus adapter.

No.	Designation	min.	max.	Default	Unit	r/w	Format	Description
303	Actual operating status	0	65535	0		r	u16	Bit 0: Normal operation Bit 1: Ready for switch on Bit 2: Speed is increasing Bit 3: Speed is dropping Bit 4: Generator operation Bit 5: Stand-by Bit 6: reserved Bit 7: reserved
312	Catalogue number (Index 0...10 usable)	0	127	800075V0001		r	u16	P/N of the converter. One ASCII character per index.
313	Product name (Index 0...10 usable)	0	127	TD_CLASSIC		r	u16	Product name of the converter. One ASCII character per index.
315	Serial number converter (Index 0...10 usable)	0	127	0		r	u16	Serial number of the converter. One ASCII character per index.
316	Hardware rev. level	0	65535	0	0.01	r	u16	Hardware version index of the converter.
318	Function optional relay 3	0	5	5		R/W	u16	0 = Off 1 = On 2 = Warning 3 = Fan (active only for driven pump) 4 = Fan (temperature controlled) 5 = Motor current dependent normal operation (active for P5 < 27)
918	Active Profibus address	0	126	0		r	s16	Address set up at the Profibus adapter.
947	Active failure ID	0	55	0		r	s16	Currently present error. See Section 3.2.10 as to the error codes.

3.2.9 Specific parameter data for the pumps

Type of pump	Pump-designation TURBOVAC	Nominal-and setpoint frequency P18, P24	Critical frequency threshold P20	Maximum run-up time P32	Pump housing warning temperature P128	Pump housing shutdown temperature P132
P23						
0	1100 (C)	500	300	720	70	80
1	1000 (C)	600	350	600	70	80
2	600 (C)	600	350	600	70	80
3	361 (C)	750	450	600	55	65
4	151 (C)	833	550	600	55	65

Operation

3.2.10 Error messages

No. at Error Mode 0 and 1*	Mode 2**	Shut-down	LED	Description	Condition
0	0	No		No error	
1	101	No		Overload warning	$P3 < P25 \cdot P24$ (after normal operation has been attained) (not during generator operation!).
3	103	No		Power supply voltage error	Power supply voltage failure during active pump operation.
4	5	Yes	5	Converter temperature error	$P11 > \text{limit threshold converter temperature}$.
6	106	Yes	4	Overload error	$P3 < P20$ after normal operation was attained.
7	6	Yes	3	Run-up time error signal being present.	$P3 < P24 \cdot P25$ after P32 has elapsed with start
8	8	Yes	2	Pump error	Pump could not be identified or no pump has been connected.
10	3	Yes	6	Pump temperature error	$P127 > P132$ or temperature switch = ∞
16	116	Yes	4	Overload duration error	$P3 < P25 \cdot P24$ longer of than P32.
17	117	Yes	1	Motor current error	No motor current or motor current too low.
19	2	Yes	3	Pass-through time error	$60 \text{ Hz} < P3 < P20$ after P183 has elapsed with the start signal being present
43	143	Yes	8	Internal error	
60	4	Yes	7	Hardware monitoring	Short-circuit within the motor or connecting cable (overcurrent, overvoltage, air cooler defective)
62	62	No		Pump temperature warning	$P127 > P128$
> 100	> 200	Yes	7	Internal error	Error within the converter or external voltage applied to the inputs

* Error modes 0 and 1 are compatible with TD 1600 and MAG.DRIVE.

** Error mode 2 is the default setting for the TD20 classic.

The error mode can be set in Parameter 90.

3.3 Start-up of the TURBOVAC

Press the START key.

The STATUS LED **flashes** during acceleration. The LED chain indicates the increasing speed with one LED each. When 80% of the target speed has been reached, the LED STATUS remains on continuously.

During normal operation the row of LEDs will indicate the amount of power taken up by the TURBOVAC.

3.4 Operation

During NORMAL operation, the LED STATUS lights and the LED chain shows, starting at the bottom and moving upwards, the current consumed.

If the target speed of the TURBOVAC cannot be maintained during normal operation due to overloading (pressure, excessive TURBOVAC or Turbo.Drive TD20 ^{classic} temperature), the LED ERROR flashes.

The mode is not a failure, but can result in a shut down depending on the cause of overload, e.g. if the temperature continues to rise.

3.4.1 Status table at default settings

(Parameter 29=0; Normal operation threshold at 80% of the nominal value)

Input data / status				Output data					Operating mode
Start/ stop signal	Pump rotating	Frequency ≥ 80% of setpoint fr.	Error is pre- sent	Motor drive	Relay NORMAL OPERATION	Relay ERROR	LED STATUS (green)	LED ERROR (red)	
Stop	no	no	no	off	passive	passive	off	off	Pump not operating
Stop	yes	no	no	off	passive	passive	flashes	off	Pump is decelerating
Stop	yes	yes	no	off	passive	passive	flashes	off	Just after stop; pump was in the normal operating mode before that
Start	no	no	no	on	passive	passive	flashes	off	Just after start
Start	yes	no	no	on	passive	passive	flashes	off	Pump is accelerating
Start	yes	yes	no	on	active	passive	on	off	Pump is in the normal operating mode
Stop	no	no	yes	off	passive	active	off	on	Error is present; pump is at standstill or decelerating
Stop	yes	no	yes	off	passive	active	flashes	on	Error is present; pump is decelerating
Stop	yes	yes	yes	off	passive	active	flashes	on	Error has just occurred
Start	no	no	yes	off	passive	active	off	on	Error is present; pump is at standstill or decelerating
Start	yes	no	yes	off	passive	active	flashes	on	Error is present; pump is decelerating
Start	yes	yes	yes	off	passive	active	flashes	on	Error has just occurred

3.5 Shut-down of the TURBOVAC

Press the STOP key.

While the pump runs down, the STATUS LED flashes. The TURBOVAC runs down until it stands still.

The row of LEDs indicates the decrease in speed through one LED each. The rotational speed can only be indicated down to approximately 250 Hz, i.e. the STATUS LED goes out before the pump has come to a standstill.

Warning



Before working on the pump make sure that the pump is at standstill.

3.6 Shut-down of the Turbo.Drive TD20 classic

Press the STOP key.

Set the mains switch on the rear to the position "0".

4 Maintenance

The converter essentially requires no servicing since it contains no components which could be adjusted.

Depending on the installation particulars and the ambient conditions, the converter may collect grime (dust, moisture) on the inside. Such contamination can lead to malfunctions, overheating or short circuits and will have to be avoided to the maximum extent possible. The Leybold Service Department can clean the converter. We recommend adhering to a cleaning interval of about three years.

Warning



Only qualified personnel or the Leybold Service Department may carry out work on the frequency converter.

Potentially fatal voltages are present inside the frequency converter. Open the frequency converter only after it has been isolated from the mains power supply.

The converter contains components which could be damaged by electrostatic discharges.

5 Troubleshooting

When a malfunction occurs, the TURBOVAC is no longer driven and a failure code is indicated.

The red LED ERROR lights permanently and one green LED within the chain flashes.

After you have eliminated the cause of the failure, you can reset the malfunction signal with the STOP command (key or remote control).

Only qualified personnel or the Leybold Service Department may carry out work on the frequency converter.

Potentially fatal voltages are present inside the frequency converter. Open the frequency converter only after it has been isolated from the mains power supply.

Warning



Symptom	Probable Cause	Remedy
Turbomolecular pump produces strong running noises and vibrations.	Rotor imbalance. Defective bearing	Have the rotor balanced. Replace the bearing.
Turbomolecular pump does not attain its ultimate pressure.	Defective measuring instrument. Contaminated gauge head. Leak at the apparatus, lines or the pump. Contaminated pump. Inadequate pumping speed of the backing pump or ultimate pressure is too high. Incorrectly programmed frequency parameters.	Check the measuring instrument. Clean or replace the gauge head. Leak search. Clean the pump. Check the ultimate pressure supplied via the backing pump; if required installed a larger backing pump. Check the parameters.
The running pump cannot be stopped through the keys or X1.	The pump was started through the serial interface.	Disconnect the AC supply or provide a serial link and stop through bus.
The pump cannot be started through X1.	The pump was stopped through the keys; see Section 3.2.1.	At first give a stop command through X1, then start.
The pump cannot be stopped through X1.	The pump was started through the keys; see Section 3.2.1.	At first give a start command through X1, then stop.

Troubleshooting

Symptom	Probable Cause	Remedy
LED 1 (left) flashes Line cord fault	Motor connection line incorrectly schlossen connected. Motor connection line malfunctioning.	Check the motor connection line and connect it correctly. Replace the motor connection line.
LED 2 flashes Pump error	Pump could not be identified or no pump has been connected. Frequency converter and pump are not compatible. Connecting cable provides only an intermittent contact.	Check the system. Check the system. Replace the connecting cable.
LED 3 flashes Run-up time error	Forevacuum pressure $>10^{-2}$ mbar. Pump blocked. High vacuum pressure too high.	Check the forevacuum. Inform the Leybold after-sales service. Check the vacuum chamber.
LED 4 flashes Overload error	Forevacuum pressure $>10^{-2}$ mbar. Pump blocked. High vacuum pressure too high.	Check the forevacuum. Inform the Leybold after-sales service. Check the vacuum chamber.
LED 5 flashes Converter temperature error, temperature in the Turbo. Drive TD20 ^{classic} is too high.	Frequent switching between acceleration and braking. Ambient temperature too high. Forevacuum pressure $>10^{-2}$ mbar.	Let the Turbo.Drive TD20 ^{classic} cool down. Ensure an adequate ventilation. Operate the pump under normal load only.
LED 6 flashes Pump temperature error, temperature in the TURBOVAC is too high.	Frequent switching between acceleration and braking. Poor cooling or cooling line interrupted.	Let the pump cool down and operate under normal load only. Check the cooling.
LED 7 flashes Internal error	Error during POST.	Inform the Leybold after-sales service.
LED 8 flashes Rotary speed error, speed of the pump does not correspond to the requirements.	Error during POST.	Inform the Leybold after-sales service.
LED 9 is not used.		
Two of the LEDs 1 to 5 flash, TURBO.DRIVE has detected a different pump.	Pump or frequency converter were changed.	Run special acknowledgement, see Chapter Installation.

EU Declaration of Conformity

(Translation of original Declaration of Conformity)

The manufacturer: Leybold GmbH
Bonner Strasse 498
D-50968 Köln
Germany

herewith declares that the products specified and listed below which we have placed on the market, comply with the applicable EU Council Directives. This declaration becomes invalid if modifications are made to the product without agreement of Leybold GmbH.

Product designation: Frequency Converter

Type designation: Turbo.Drive TD 20 classic

Part numbers: 800075V0001, 800075V0002, 800075V0003, 800075V0004,
800075V0005

The products complies to the following European Council Directives:

Low Voltage Directive (2014/35/EU)

Electromagnetic Compatibility (2014/30/EU)

The following harmonized standards have been applied:


EN 61010-1:2010 Safety requirements for electrical equipment for measurement, control, and laboratory use — Part 1: General requirements

EN 61326-1:2013 Electrical equipment for measurement, control and laboratory use — EMC requirements — Part 1: General requirements
Emissions: Group 1, Class A
Immunity: Industrial electromagnetic environment

Documentation officer: Herbert Etges
T: +49(0)221 347 0
F: +49(0)221 347 1250
documentation@leybold.com

Cologne, November 16, 2016

Cologne, November 16, 2016



ppa. Martin Tollner
Head of Product Lines



ppa. Dr. Monika Mattern-Klosson
Head of Quality & Business Process Management

Document No.: 300643530-002-A0

The frequency converter **Turbo.Drive TD20^{classic}** has been tested by the TÜV Rheinland of North America according to the requirements of

■ **NRTL**

(used standard UL 61010-1: 2004)

■ **SEMI F47-0200**

It is in compliance to the tested standards.

The Part Nos. 800075V0001 to 800075V0007 have been checked.

The other frequency converters have not yet been tested by the TÜV, they are designed and tested following the same regulations.

Certificate No. 72063165 01



**NRTL
LISTED**

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Sales and Service

Germany

Leybold GmbH

Sales, Service, Support Center (3SC)
Bonner Strasse 498
D-50968 Cologne
T: +49-(0)221-347 1234
F: +49-(0)221-347 31234
sales@leybold.com
www.leybold.com

Leybold GmbH

Sales Area North

Branch Office Berlin
Industriestrasse 10b
D-12099 Berlin
T: +49-(0)30-435 609 0
F: +49-(0)30-435 609 10
sales.bn@leybold.com

Leybold GmbH

Sales Office South

Branch Office Munich
Karl-Hammerschmidt-Strasse 34
D-85609 Aschheim-Dornach
T: +49-(0)89-357 33 9-10
F: +49-(0)89-357 33 9-33
sales.mn@leybold.com
service.mn@leybold.com

Leybold Dresden GmbH

Service Competence Center

Zur Wetterwarte 50, Haus 304
D-01109 Dresden
Service:
T: +49-(0)351-88 55 00
F: +49-(0)351-88 55 041
info.dr@leybold.com

Europe

Belgium

Leybold Nederland B.V.

Belgisch bijkantoor

Leuvensesteenweg 542-9A
B-1930 Zaventem
Sales:
T: +32-2-711 00 83
F: +32-2-720 83 38
sales.zv@leybold.com
Service:
T: +32-2-711 00 82
F: +32-2-720 83 38
service.zv@leybold.com

France

Leybold France S.A.S.

Parc du Technopolis, Bâtiment Beta
3, Avenue du Canada
F-91940 Les Ulis cedex
Sales and Service:
T: +33-1-69 82 48 00
F: +33-1-69 07 57 38
info.ctb@leybold.com
sales.ctb@leybold.com

Leybold France S.A.S.

Valence Factory
640, Rue A. Bergès
B.P. 107
F-26501 Bourg-lès-Valence Cedex
T: +33-4-75 82 33 00
F: +33-4-75 82 92 69
marketing.vc@leybold.com

Great Britain

Leybold UK LTD.

Unit 9
Silverglade Business Park
Leatherhead Road
Chessington
Surrey (London)
KT9 2QL
Sales:
T: +44-13-7273 7300
F: +44-13-7273 7301
sales.ln@leybold.com
Service:
T: +44-13-7273 7320
F: +44-13-7273 7303
service.ln@leybold.com

Italy

Leybold Italia S.r.l.

Via Trasimeno 8
I-20128 Mailand
Sales:
T: +39-02-27 22 31
F: +39-02-27 20 96 41
sales.mi@leybold.com
Service:
T: +39-02-27 22 31
F: +39-02-27 22 32 17
service.mi@leybold.com

Netherlands

Leybold Nederland B.V.

Floridadreef 102
NL-3565 AM Utrecht
Sales and Service:
T: +31-(30) 242 63 30
F: +31-(30) 242 63 31
sales.ut@leybold.com
service.ut@leybold.com

Switzerland

Leybold Schweiz AG, Pfäffikon

Churerstrasse 120
CH-8808 Pfäffikon
Warehouse and shipping address:
Riedthofstrasse 214
CH-8105 Regensdorf
Sales:
T: +41-44-308 40 50
F: +41-44-302 43 73
sales.zh@leybold.com
Service:
T: +41-44-308 40 62
F: +41-44-308 40 60
service.zh@leybold.com

Spain

Leybold Spain, S.A.

C/. Huelva, 7
E-08940 Cornellà de Llobregat
(Barcelona)
Sales:
T: +34-93-666 43 11
F: +34-93-666 43 70
sales.ba@leybold.com
Service:
T: +34-93-666 46 11
F: +34-93-685 43 70
service.ba@leybold.com

America

USA

Leybold USA Inc.

5700 Mellon Road
USA-Export, PA 15632
T: +1-724-327-5700
F: +1-724-325-3577
info.ex@leybold.com
Sales:
T: +1-724-327-5700
F: +1-724-333-1217
Service:
T: +1-724-327-5700
F: +1-724-325-3577

Brazil

Leybold do Brasil

Rod. Vice-Prefeito Hermenegildo Tonolli,
nº. 4413 - 6B
Distrito Industrial
Jundiá - SP
CEP 13.213-086
Sales and Service:
T: +55 11 3395 3180
F: +55 11 99467 5934
sales.ju@leybold.com
service.ju@leybold.com

Asia

P. R. China

Leybold (Tianjin)

International Trade Co. Ltd.

Beichen Economic
Development Area (BEDA),
No. 8 Western Shuangchen Road
Tianjin 300400
China
Sales and Service:
T: +86-22-2697 0808
F: +86-22-2697 4061
F: +86-22-2697 2017
sales.tj@leybold.com
service.tj@leybold.com

India

Leybold India Pvt Ltd.

No. 82(P), 4th Phase
K.I.A.D.B. Plot
Bommasandra Industrial Area
Bangalore - 560 099
Indien
Sales and Service:
T: +91-80-2783 9925
F: +91-80-2783 9926
sales.bgl@leybold.com
service.bgl@leybold.com

Japan

Leybold Japan Co., Ltd.

Headquarters
Shin-Yokohama A.K.Bldg., 4th floor
3-23-3, Shin-Yokohama
Kohoku-ku, Yokohama-shi
Kanawaga 222-0033
Japan
Sales:
T: +81-45-471-3330
F: +81-45-471-3323
sales.yh@leybold.com

Leybold Japan Co., Ltd.

Tsukuba Technical Service Center
1959, Kami-yokoba
Tsukuba-shi, Ibaraki-shi 305-0854
Japan
Service:
T: +81-29 839 5480
F: +81-29 839 5485
service.iik@leybold.com

Malaysia

Leybold Malaysia

Leybold Singapore Pte Ltd.

No. 1 Jalan Hi-Tech 2/6
Kulim Hi-Tech Park
Kulim, Kedah Darul
Aman 09000
Malaysia
Sales and Service:
T: +604 4020 222
F: +604 4020 221
sales.ku@leybold.com
service.ku@leybold.com

South Korea

Leybold Korea Ltd.

3F. Jellzone 2 Tower
Jeongja-dong 159-4
Bundang-gu Sungnam-si
Gyeonggi-do
Bundang 463-384, Korea
Sales:
T: +82-31 785 1367
F: +82-31 785 1359
sales.bd@leybold.com
Service:
623-7, Ulsung-Dong
Cheonan-Si
Chungcheongnam-Do
Korea 330-290
T: +82-41 589 3035
F: +82-41 588 0166
service.cn@leybold.com

Singapore

Leybold Singapore Pte Ltd.

8 Commonwealth Lane #01-01
Singapore 149555
Singapore
Sales and Service:
T: +65-6303 7030
F: +65-6773 0039
sales.sg@leybold.com
service.sg@leybold.com

Taiwan

Leybold Taiwan Ltd.

No 416-1, Sec. 3
Chunghsin Rd., Chutung
Hsinchu County 310
Taiwan, R.O.C.
Sales and Service:
T: +886-3-500 1688
F: +886-3-583 3999
sales.hc@leybold.com
service.hc@leybold.com

Headquarter

Leybold GmbH

Bonner Strasse 498
D-50968 Cologne
T: +49-(0)221-347-0
F: +49-(0)221-347-1250
info@leybold.com



www.leybold.com