



## **TURBO.CONTROL i** **Display Unit**

smart controller for TURBOVAC i/iX  
turbomolecular pumps


# Smart monitoring and control

## for your TURBOVAC i/iX turbomolecular pumps

**The TURBO.CONTROL i operates one TURBOVAC i/iX at a time. It can be connected to all TURBOVAC i/iX models for control and data read out on-site**

This unit is rack mountable as standard, a table top housing can be purchased separately.

- Two communication channels (RS 485 and USB) are available for pump control and ports for the connection of up to two gauges.
- Operation is carried out via display and front keys or the pre-installed webserver software.
- The integrated Ethernet port allows the connection of a PC to access the platform independent webserver with any common browser. Via the webserver all pump parameters can easily be viewed and adjusted by PC or mobile devices (requires a wireless router installation).
- Main parameters are also written into the log file.



## Easily view the log file using TURBO. CONTROL i data viewer software tool

It can be downloaded from our website (Visit [www.leybold.com](http://www.leybold.com)).

This MS Windows software tool analyzes the data and event log files. It monitors the status and key parameters.

The TURBO.CONTROL i software tools excel with intuitive operating menus and simple operation, thus providing a new and comfortable user experience.

## Technical data

Front view / rear side  
with connections & slots



Mains input	24 VDC – 1,5 A – 36 W
Connectable sensors	
THERMOVAC	TTR 91, TTR 91 , TTR 101, TTR 101 N
PENNINGVAC	PTR 90, PTR 90 N
Interfaces	RS 485, USB, RJ-45 COM
Operational temperature	0 to +45 °C
Storage temperature	-20 to +45 °C
Permissible air humidity	< 60% rH, non-condensing
Dimensions (W x H x D)	106 x 128,5 x 33 mm
Protection type / class	IP 20/III
Weight	320 g

## Ordering information

TURBO.CONTROL i display unit with RS 485/USB interface, RJ-45 COM interface for PC connection & ports for up to two gauges	800100V0004
Power supply 24 VDC / 1.5 A	800110V0027
Table top housing	800110V0028
USB cable 2.0 type A/B, 1.8 m	800110V0108
RS485 cable 5 m	800103V0029
RS485 cable 1 m	800103V0027
Webserver software	pre-installed



Pioneering products. Passionately applied.